

DATASHEET PBXware 7.0



wiki.bicomsystems.com

PBXware Editions

PBXware is the world's first and most mature IP PBX Professional Open Standards Turnkey Telephony Platform. Since 2004, PBXware has deployed flexible, reliable, and scalable New Generation Communication Systems to SMBs, enterprises, and governments worldwide by unifying the most advanced of the latest technologies. PBXware is offered in the Business, Contact Center and Multi-Tenant Editions, each supporting specific features maximizing performance, reliability, and expandability.

MULTI-TENANT EDITION

The Multi-Tenant Edition of PBXware gives Telecom Service Providers a powerful platform to serve the IP PBX market in the cloud as a VoIP switch. Unlimited Hosted IP PBX Multi-Tenants, Unlimited resellers, user/company self-portal, and LCR are just a few of the advanced features included with desktop applications.

BUSINESS EDITION

PBXware Business edition is our extensive and fully customizable platform providing you with a comprehensive set of features and capabilities of the enterprise phone system. Transform the way you conduct business and increase efficiency in the workplace by truly unifying your communication system. As you grow, so does your phone system!

CONTACT CENTER EDITION

PBXware Contact Center edition is designed to simplify and enhance call management at the busy call centers of any size. Give your business all the tools it needs to effectively start and manage inbound or outbound call campaigns. Upgrade to PBXware Contact Center, and provide your customers with a consistent and quality experience.

Date modified: September 19, 2023

System Dashboard			
	business	contact center	multi tenant
System dashboard			
The Dashboard section gives you overview of vital PBXware information. It displays hardware usage, main services status, information on the system and gloCOM licensing as well as the number of Total calls, Answered calls, SIP registration etc.			
TFTP service			
TFTP service removed from dashboard			
Number of provisioned extensions on the Dashboard			
Presents information on how many extensions have been provisioned/added to the system			
System Extensions			
	business	contact center	multi tenant
Protocols: SIP, IAX2, DAHDI			
PBXware extensions supports SIP and IAX2 protocols as well as DAHDI interface technology. SIP and IAX2 are communications protocols used for signaling and controlling multimedia communication sessions while DAHDI is open source computer telephony hardware driver API.			
Outbound Destinations Permissions			
Administrator have full control on what destinations, local or remote, PBX ware extensions can dial. These rules can be applied to multiple extensions at the same time (through Service Plans) or individually per extension.			
Multiple registrations			
NOTE: PBXware 5 does not have restrictions in regards to the number of registered devices, regardless of device type			

Multiple MAC addresses per one extension We have added the ability to use multiple MAC addresses per single extension. This provides the ability to auto-provision multiple phones attached to the same Extension. In practice, this could be one type of device, or multiple types of devices linked to same extension. This is similar to our Hot Desking feature.		
Push Notifications		
PBXware 5 is now running push notification service that propagates push notifications to devices that are registered to the PBXware extension with gloCOM GO. This feature increases user connectivity and flexibility for business trips, working from home, or any other calls made outside of the office.		
Enhanced Services		
Enhanced Services allows PBXware Administrators, as well as end users, to set up and control extensions features like Caller ID, Call Pickup, Call Filters & Blocking, Call Forwarding etc. from their phone and through a web interface.		
Billing		
PBXware billing module is one of the most important system components. It allows you to set up outbound and inbound billing prices for all the destinations across the globe. When Time Based Dialing (TBD) rules are used, system allows you to create different prices for the specific day/time ranges.	0	
LCR		
PBXware LCR (Least Cost Routing) section allows fine-tuning of the systems trunks usage, enabling administrator to set up order in which trunks will be used in order to strike the perfect balance between price and call quality.		
Caller ID control		
PBXware allows you complete control of your Caller ID for outbound calls. Please note that this feature will also depend on Caller ID rules enforced by your trunk provider.		
Codec selection		
PBXware allows you to set preferred order in which codecs will be used on system, tenant or extension level. This option will allow you to assign more than one codec and set them to be used under a specific priority.		

Auto-provisioning allows you to automatically configure your phones by pointing them to PBXware tftp/http address. To utilize auto-provisioning system you must use one of the desk phone devices from evergrowing PBXware list of supported UADs and configure PBXware extension with matching UAD and MAC address.		
Auto provisioning, additional config customization variables		
Additional config for Auto Provisioning on the following pages can now use template variables: Extensions > Edit > UAD Auto Provisioning Template Settings > UAD > Edit > User Agent General Auto Provisioning Template Settings > UAD > Edit > User Agent Auto Provisioning Template		
The following variables can be used: %TENANT_CODE% - tenant code %EXT_NUMBER% - extension number %EXT_NAME% - extension name		
%MAC_ADDRESS% - extension MAC address (the mac from the auto provisioning request)		
<pre>%WAN_IP% - WAN Hostname/IP set in Servers > Edit %LAN_IP% - LAN Hostname/IP set in Servers > Edit %AUTH_USERNAME% - HTTP username %AUTH_PASSWORD% - HTTP username %VM_PIN% - extension voicemail PIN</pre>		
Line Number		
When autoprovisioning multiple extensions on 1 phone, extensions are assigned onto lines in the order in which they were created in PBXware. The line field will allow customers to specify the extension line where this extension will be assigned on the device.		
An empty line number field will be treated as the last one.		

Voicemail		
PBXware voicemail is an advanced answering machine that allow callers to leave voicemail message in scenarios where calee is not able to answer the call. Although each PBXware extension is usually equipped with a voice mailbox, this feature can be turned off and if necessary, voice mailboxes can be created on their own, unrelated to any extension on your PBXware.		
Call Recording		
PBXware offers multiple options to enable call recording, defining whether you would like to inform call parties that call recoding is turned on or not. Call recording can be enabled globally, for entire system, or lower level per Tenant, DID, Extension, Ring group etc.		
Call Recordings - Listen recordings in-browser		
New PBXware 5 interface now have integrated call recordings player, allowing users to listen PBXware call recordings directly from their browser and navigate through the recording with a simple click of a mouse. This prevents the issue users might experienced with earlier versions, as they had to find a media player that supports format in which recordings were being downloaded.		
CSV upload		
CSV upload allow you to easily create multiple entries for different PBXware elements like Extensions and DIDs, or to quickly add or change prices for every destination in service plan.		
CSV Download		
CSV download gives you an option to export PBXware data in CSV format, allowing you to get information for data processing (i.e. DID or Extension list), or for importing data to another PBXware (i.e. billing prices for different destinations).		
Departments		
Departments section lists all of the departments created on your PBXware and gives you ability to add new ones or edit existing. Departments are used by Bicom Systems gloCOM to easily filter extensions per department they belong or to broadcast messages to specific department members only.		

gloCOM Modules and Editions gloCOM Editions and Modules allow you to restrict extensions to only use selected gloCOM editions and modules. This prevents users from switching their gloCOM edition to one they should not be using for sheer quriosity, preventing extensions that are actually supposed to use that particular edition from using it.		
gloCOM features administration		
We have introduced the ability for an administrator to enable/disable gloCOM features globally per system, per edition or per Tenant.		
QR Code		
QR Code allows easy first time login with gloCOM GO mobile app. Instead of entering e-mail, password and server address manually on first login all you have to do is to scan QR Code from your mobile app and all the information will be entered automatically.		
Desktop Apps integration		
PBXware offer seamless integration with gloCOM desktop app, allowing users to save time and improve productivity.		
Mobile Apps integration		
gloCOM GO mobile app allows you to stay connected to your PBXware extension even when you are not in your office, enabling you to do your work without being confined to your office desk or even your office.		
WebRTC support		
PBXware now supports WebRTC. WebRTC provides browsers and mobile applications with Real-Time Communications capabilities via simple APIs.		
PIN based devices		
Every extension is now allocated its own unique PBD PIN. This PIN will identify the user on the system and, when logged in to a PIN Based Device, dialing will proceed as though the user was calling from their own extension. Billing, CDRs and all other functions will be completed on the user extension and not the extension associated with the Pin Based Device.		

Copy extension		
A new feature in PBXware 5.1 is "Copy As New", an option to create a new extension by making copies of an existing extension's settings. This will speed up the process of adding new extensions to the system.		
Operation times per extension		
We have introduced an "Operation Times" option for extensions allowing you to control work days and hours per extension by simply adjusting this feature in enhanced services. This is also available in OSC if enabled in Enhanced Services. We have also implemented UX improvements GUI improvements in the Global Operation Times page forbetter user experience.		
Area code per extension		
Area code implemented per extension so you can define the area code which will be dialed if a specific extension makes a call without the need to dial the area code for the designated area.		
Ability to block incoming calls		
Ability to block incoming calls while having another active call . This will be used by the users who do not wish to receive incoming calls if they are already on a call (either incoming or outgoing).		
Show on the Monitor Page		
Excludes an extension from showing on the Monitor page. Useful for virtual extensions that will never be online in order to get a more accurate count of phones online.		
Operator Extension		
During initial Setup Wizard, on Business/Call Center edition Operator Extension will be assigned to the extension that is created automatically once Setup Wizard is completed (i.e. extension 1000) but can later be changed to any other extension on your system. Operator extension is central location where all the calls will be routed if call is passed through the trunk to the PBXware but its destination is wrong or does not exist. In the rare occurence this might happen when you purchase range of DIDs from your provider, but do not create a matching DID on your PBXware. In this scenario, your provider will forward the call to your system but because DID does not exist, call will be forwarded to Operator Extension instead of being dropped by PBXware.		

Ability to control default location mode when adding extensions When creating a new extension you can choose which default location will be selected.			
Support for PAI variable per extension Define what will be inserted into the trunk PAI header template.			
Add emergency trunk per extension option Ability to set emergency trunks per extension.			
Added an option to create multiple Extensions by using a template Extension Added an option to create multiple Extensions by using a template Extension. Data from the template extension will be copied to newly created extensions. Any later update of the template extension will not affect other extensions.			
Check for UAD SIP headers Added a field to pass the additional UAD SIP headers to a Trunk.			
Extensions Statistics			
Extensions Statistics represents a set of statistical reports which enable the selection of a date / time interval and desired extensions or all and different reports on all, answered, unanswered, inbound, outbound and internal calls. Customer is now able even to analyze all calls per direction made by the extension to the outside, received from the outside, or calls internally made within one PBX (for example, how many were incoming internal, outgoing internal, outgoing external etc.) with details by calls available such as talk time, wait time, type of call (whether it was a conference call or not) etc.	business	contact center	multi tenant
Filters			
Users can filter reports by time range, caller, and Extensions when using regular filter options. In the case of using advanced filtering options, the user can filter reports by call duration and hold duration using different time formats. Filters are also used to select the reports the user wants to display. The reports will then be moved to a "Selected Reports" section. Clicking the "Show" button will open a new window with the selected reports.			

All Answered Calls		
This report provides an overview of all answered calls, talk time, and hold time. Talk time contains information such as Total duration of all answered calls, Min - Minimum duration of a single answered call, Max - Maximum duration of a single answered call, and Mean - Average talk time value for all answered calls. Hold time contains information such as Total duration of hold time for all answered calls, Min - Minimum hold time for a single answered call, Max - Maximum hold time for a single answered call, and Mean - Average hold time for all answered calls.		
All Calls		
The All Calls report offers an overview of all calls that have occurred on the system and all calls disposition. The All Calls report contains information such as Talk time (Total, Min, Max, and Mean) and Hold time (Total, Min, Max, and Mean). All Calls Disposition contains information such as total, answered calls, percentage of answered calls, unanswered calls, and percentage of unanswered calls).		
All Unanswered calls		
This report provides an overview of all unanswered calls and hold times. The All Unanswered Calls report shows the sum of all unanswered calls, while the Hold Time shows the total wait time for all missed calls, the minimum and maximum wait time for all unanswered calls, and the average value of the hold time for all missed calls.		
Calls Per Direction		
This report provides an overview of calls per direction (incoming external, incoming internal, outgoing external and outgoing internal). Report contains additional information such as Name (name and number of the caller extension), Calls (number of all, answered and unanswered calls and Talk Time (total talk time, mean talk time per direction and average delay time for call per direction).		

Inbound Calls This report provides an overview of all inbound calls, talk time, hold time, and all inbound calls disposition containing information such as talk time (total inbound talk time, minimum duration of a single inbound call, maximum duration of a single inbound call, and average talk time value for all inbound calls), hold time (total inbound hold time, minimum hold time duration of a single inbound call, maximum hold time duration of a single inbound call and average hold time value for all inbound calls), and all inbound calls disposition (total, answered, percentage of answered, unanswered, percentage of unanswered inbound calls).		
Internal Calls		
This report provides an overview of all internal calls per direction (incoming or outgoing) with additional information such as Extension (name and number), calls (total number per direction, answered and unanswered calls per direction), and talk time (total internal calls talk time, the average value of internal calls talk time).		
Outbound Calls		
This report provides an overview of all outbound calls, talk time, hold time, and all outbound calls disposition. Talk/hold time contains information such as total outbound talk/hold time, minimum and maximum talk/hold time duration of a single outbound call, and average talk/hold time value for all outbound calls. Outbound Calls dispositions show total, answered, percentage of answered, unanswered, and percentage of unanswered outbound calls.		
Breakdown		
A breakdown of any report contains information such as the linked ID - the event ID, the date the event occurred, the name and number of the Extension from which the call was initiated, the destination number that was called, the time the caller waited for the call to be answered, the time spent on the call, information whether it was a conference call or not, the type of call (Incoming Internal, Incoming External, Outgoing Internal, Outgoing External).		

Download CSV			
The Download CSV option lets the user download the CSV formatted file with all calls in the breakdown.			
Billing			
PBXware billing module is a vital tool that provides easy management of service plans, extension funds and allows full control over pricing and billing for outbound and inbound calls.	business	contact center	multi tenant
Service Plan			
Service plan defines billing details for all available destinations but it will also enable you to create a template for PBXware Enhanced Services, Destinations permissions and Online Self Care settings which all will be automatically applied to every extension associated with particular service plan.	0		
Master / Slave accounts			
Depending on your preferences extension can have its own funds (master) or share funds with master extensions (slave). Setting one extension as "master" and rest of the extensions as "slave" can be very usefull and would improve billing management as with this setup you will have a single point for managing funds and billing, instead of doing it for each of the extensions individually.	0		
Credit Limits			
Credit limits allow you to assign maximum amount of funds extensions will be able to spend on calls, preventing users from having unlimited funds at their disposal.	0		
Soft and Hard Daily / Monthly Billing Limits			
Once Soft Limit is reached on extension PBXware will send email notification to user, informing him that extensions funds are getting low and in case Hard Limit is reached PBXware will block all outbound calls for this extension. Soft and Hard Limit can be set on daily or monthly basis. Setting these two values will prevent users from having unlimited funds at their disposal.	0		

Inclusive Minutes Assigning certain number of inclusive minutes to a service plan will allow users to make calls to destinations set up to use inclusive minutes, free of charge until all inclusive minutes are spent. At that point, extension will start using available funds. Destinations that not set up to use inclusive minutes will be charged according to price set in service plan.	0		
Outbound Destinations Permission	S		
	business	contact center	multi tenant
Destination Groups			
Permissions per destination groups enable you to restrict dialing to specific domestic or international destinations, or even to all international destinations if necessary. This feature can be set on service plan level or set and modified per extension.			
Local Destinations			
In addition to permissions per destination group PBXware allows you to restrict calls to local destinations such as local extensions, auto attendants, conferences, queues etc. This feature can be set on service plan level or set and modified per extension.			
Other Networks			
Other Networks feature allows administrator to assign specific prefix to some of the PBXware trunks. This will allow users to dial assigned prefix in order to force call to be made through specific trunk.			
NOTE: Please be aware that when Other Networks features is used billing module will be overridden and calls made this way would not be billed.			
Special Routes			
Special Routes feature allows PBXware administrator to add special services numbers that will be distinguished from extensions numbers (even if they have same number of digits) and dialed through specified trunk, similar to how Emergency Services numbers are dialed through Emergency Trunk.			

Enhanced Services			
	business	contact center	multi tenant
Caller ID			
Caller ID feature allows users to create and control caller ID number that will be displayed to the called party.			
In addition to seting permanent call that will be used as primary Caller ID, administrator can create a list of allowed caller IDs that can be selected before the call is initiated. This feature is intended to be used with gloCOM desktop app but it can also be used by entering access code on the deskphone.			
Call Pickup			
Call Pickup feature enables users to pickup calls that are ringing other extensions in associated call groups. Along with call pickup enabling you to pick calls that are ringing any extension in your call group by simply dialing *8, it is possible to use directed pickup and pick calls from specific extension by dialing *88 + EXTENSION.			
Last Caller			
Last Caller allows users to dial the last number that dialed their number by entering access code. This is basically a redial feature intended to be used on phones without display screen or analog phones that are registering to PBXware through ATA devices.			
Call Filters & Blocking			
Based on a set of predefined rules this service filters and blocks all incoming calls based on the rules you have set for incoming caller IDs. This way, you are able to send busy signal to all calls that have their caller ID hidden, or to forward the call to out of service number whenever specific number dials your extension.			
Do Not Disturb			
When enabled Do Not Disturb service can block and temporarily or permanently redirect all incoming calls to preferred destination number.			

Call Screening		
Call screening enables user to forwards calls to other extensions depending on users extension status.		
Disable Call Screening for local calls		
Added the option to skip call screening for local calls.		
Call Forwarding		
Call Forwarding service forwards calls to other destinations depending on the rules created for particular extensions status. For example, you can forward calls to your cell phone in case you do not answer the call in 15 seconds or in case your extension becomes unavailable for some reason.		
Configure call forwarding for internal and external calls separately		
Check the "Different Rules for Local calls" box on the Call forwarding section. Checking this box will show a table where you can define different rules for Local Calls.		
Whitelist caller IDs that won't be forwarded		
An Exclude list has been added where you can enter Caller IDs that will not be call forwarded.		
Follow Me		
Follow Me service rings destinations in a sequence set up by user. If call is not answered by initial destination next destination in sequence will be dialed. This allows you to set up your deskphone to ring first, for example 10 seconds, and if call is not answered it will move forward and ring your cell phone for 10 seconds. In case you are unable to answer it, you can also set the call to return to your extensions voicemail, ensuring that you will receive the message from the caller once you are available.		
Group Hunt		
Group Hunt service rings all provided destinations at the same time. In case where call is not answered by any of the destinations, it can be forwarded to 'Last Destination' extension that can be set to voicemail.		

Mobile Numbers		
With Mobile Numbers you can assign Mobile Numbers you would like to receive calls on when not in the office. If you enable Mobile Numbers service and add a number to the mobile numbers list it will be displayed in gloCOM as one of the destinations you can be reached on.		
Speakerphone Page		
Speakerphone Page allows you to broadcast voice message to multiple extensions at the same time through the deskphones intercom. You can either create a list of specific Extensions you would like to page or you can add ALL extensions to avoid typing in all extensions numbers on the system/tenant. In addition to this, PBXware allows directed paging, in case you would like to broadcast the message to specific extension only, and even directed two-way paging where user is be able to broadcast the message and listen the response from other party.		
Speakerphone Paging Groups		
Paging Groups feature works similar to standard paging, except this feature allows you to organize extensions to multiple paging groups and assign unique number to each of them. As this feature is used with access code *600, paging group number is entered after the access code. For example, if we assign number 300 to paging group and add 4 extensions to it, once we dial *600300 we will be able to broadcast the message over intercom to all the extensions added to paging group 300. In Enhanced Services we are only able to allow or disallow whether extension will be able to use this service, while paging groups are created at Home → Extensions →		
Paging groups. Directory / BLF List		
The directory is used to enter list of extensions you would like to have as contacts.		
When used with the Busy Line Field enabled phone, you can select some of those extensions to be monitored through BLF buttons on your phone.		

The ability to manage BLF buttons on Yealink devices		
This new feature allows Yealink users to configure phone BLF buttons from a PBXware interface just like they would in the phone web interface.		
BLF cleanup		
BLF buttons that are not set by autoprovisioning will be cleared if a checkbox has been selected. Supported phones: Cisco SPA and the newest Cisco models Fanvil phones Gigaset Maxwell series Grandstream GXP series Grandstream GRP series Htek UC9xx series Obihai phones Vtech phones Yealink phones Snom phones Sangoma phones Polycom phones		
Speed Dial		
Speed Dial service allows you to assign short code (up to 3-digits) to numbers you frequently dial so you don't have to type full number every time. To use Speed Dial you must dial '130 in front of your assigned short code (for example, *130 13).		
Instant Recording		
Instant Recording service allows you to start call recording at any point of the call. To start recording the call, user simply have to dial *159 access code.		

Delete Recordings		
Delete Recordings will give permission to end user to delete recorded calls from their personal CDR list they can reach by logging into their Online Self Care portal. Recordings will be deleted from the system, not just from users OSC CDR list. Although users can only delete recording from the calls they made, you should be careful to which users this permissionis assigned to.		
Listen to Recordings		
This service allows user to listen recorded calls by downloading them from Online Self Care portal or by dialing access code *170 on your phone and then pressing numbers 1-9 for last 9 recordings, 1 being the newest.		
Remote Access		
Remote Access enables users to dial into the system from remote location and authenticate to their personal extensions so they could make calls as if they were using their office phone.		
Call Monitoring		
This service monitors active calls in real time, allowing you to choose between three different monitoring options if needed. Listening - user can only listen to the calls Whispering - user can listen to the conversation and talk only to the monitored extension Barging - user can listen and talk to both parties on call All (Dynamic mode) - dynamically choose what mode of monitoring you want to use during the call		
Phone Callback		
Phone callback allows you to set up one or more Caller IDs that will be matched once call gets to your PBXware. Once caller ID is matched, call is dropped and user will receive the call from PBXware. Once call is answered user is able to dial any destination as if he was using office phone.		

"Confirm Calls" disabled for local destinations			
If enabled this will force the confirmation of the calls for local destinations.			
The option is available on ""Group Hunt"" and ""Follow Me"" Enhanced services.			
(external numbers still have to be confirmed).			
Wake-up calls			
A user can now call an access code *611 and use an IVR to set up a wake up call.			
They can also set up wake up calls for other extensions by calling *612. An admin must grant them this privilage by enabling the enhanced service for them.			
Added the 'Allow ES CallerID' option to ES 'Group Hunt' and ES 'Follow Me'			
Added the 'Allow ES CallerID' option to ES 'Group Hunt' and ES 'Follow Me'.			
Custom Extensions			
	business	contact center	multi tenant
Custom routing via dial plan			
For advanced users PBXware allows custom modifications directly from the dialplan			0
configuration file, allowing you to customize routing beyond settings available in PBX ware GUI.			J
Hot Desking			
Hot Desking is a feature that allows employees to work at any available desk in an office and still be able to have their own extension. If phone is set up to be used with hot desking any user can log in to their own extension by entering extension number and PIN. Only specific Polycom and Yealink devices are supported for hot desking.	business	contact center	multi tenant
Polycom			
Hot desking support for Polycom devices - All Polycom devices			
Yealink	_		_
Hot desking support for Yealink devices - All Yealink devices except T18			
Cisco			
Hot desking support for Cisco devices - 8865, 8851, 8841, 7821, 6851, 525G2, 509G			
and 508G			

HTek		
Hot desking support for HTek devices - All HTek UC9XX devices		
Grandstream		
Hot desking support for GXP1625, GXP1628, GXP1630, GXP1782 and GXP2170		
Hot desking support for Grandstream GRP series phones		
Gigaset		
Hot desking support for Gigaset Maxwell Basic, 2, 3, and 4.		
Emergency Caller ID Field		
The emergency Caller ID field is attached to the Hotdesking entry, so when a phone logs in from a remote location, the Emergency Called ID field under Enhanced Services will be replaced by the Hotdesking one.		
Log out without PIN		
To log out from a Hot Desking device, a user will need to dial *555 while logged in and this will log them out immediately.		
Minor database editing is required for this feature to be enabled.		
HotDesking page - 'Logout' device button		
Introduced a new optional button for each device on the HotDesking page to log out the device from the GUI. The button will only be visible if the device is currently logged in.		
MAC address is in use		
HotDesking warning shown when an existing MAC address is in use.		
Option to disable auto dialing of the Hot desking Access code		
Added an option to enable/disable automatic dialing of the hot desking access code.		

Caller ID List			
A list of all extensions and assigned Caller IDs and Emergency Caller IDs.	business	contact center	multi tenant
Caller ID/E911 summary			
A list of all extensions and assigned Caller IDs and Emergency Caller IDs.			
Ring Groups			
Ring Groups are used to group a number of UADs/Phones into one network destination. Each Ring Group is assigned a network number which, once dialed, rings all extensions assigned to the group according to ring strategy.	business	contact center	multi tenant
Strategy: All			
Ring strategy All will ring all available extension at the same time.			
Strategy: Round			
Round ring strategy will ring each available extension in specific order.			
Strategy: Round Memory			
Round Memory ring strategy will ring each available extension in specific order but it will begin with the extension that was last to ring on previous call.			
Strategy: Least Recent			
Least Recent ring strategy will ring extension with least answered calls.			
Ringtone customisation			
PBXware allows you to set up your ring group so phones use a different ringing sound if calls are coming from ring group.			
Caller ID customisation			
Allows you to append preferred string to incoming caller ID number in order to distinguish calls coming from ring group from other calls to extension.			
Custom greeting			
Custom greeting can be played to callers once their call enters the ring group.			

Exit Digit		
Exit digit can be set to transfer ring group call to destination assigned as "Exit Destination", usualy an operator extension.		
Incoming Call Confirmation		
Enable Confirm Calls option to allow ring group members to be asked whether they would like to accept or reject the call coming from the ring group.		
Paging Groups		
Paging Groups feature works similar to standard paging, except this feature allows you to organize extensions to multiple paging groups and assign unique number to each of them. As this feature is used with access code *600, paging group number is entered after the access code. For example, if we assign number 300 to paging group and add 4 extensions to it, once we dial *600300 we will be able to broadcast the message over intercom to all the extensions added to paging group 300.		
Store Unanswered CDRs		
Exclude unanswered CDR records from the report. If the option is set to 'yes' or 'not set' ring groups will behave the same as before. If the option is set to 'no' the following will change:		
• The call was not answered/canceled: Instead of 2 generated CDRs per extension in the ring group, only a single CDR will be stored.		
• The call was answered: Instead of 2 generated CDRs per extension in ring group a total of 2 CDRs will be generated (one for the call to the ring group and one for the extension that answered).		
Operation times for "Ring groups"		
Set the "Ring group" open/closed times. Depending on the time when the call is received, the call can be redirected to different PBXware destinations.		

Limited maximum number of Extension that may be dialed when ring strategy is "All"			
When strategy is "All" the default number of Extensions that may be dialed in a single Ring Group is set to 30. The limitation number for Ring Groups can be changed if additional configuration is set differently.			
Call Rating Extension			
Added an option to set Call Rating Extension for Ring Groups. Setting it will use that extension to bill calls made from the Ring Group to the final destination.			
Loop option improved			
Added ability to loop set of extensions multiply times like queue, instead of looping single extensions multiply times.			
Ring Groups renamed to Dial Groups			
Ring Groups are now named Dial Groups.			
Enhanced Ring Groups			
Enhanced Ring Groups (ERG) are more advanced Ring groups into PBXware that offer basic queueing functions. They are reusing Queues with members to achieve better business intelligence. New reporting systems were implemented together with leading options for a better reporting experience.	business	contact center	multi tenant
Search by name and number			
Filtering the records by providing a search phrase.			
Import from queues			
Provides the ability to quickly create new ERGs from existing queues.			
Add/Edit ERG			
ERG Name			
Possibility to set an ERG name/provide a unique ERG name.			
ERG Number			
Possibility to set an ERG number which needs to be dialed in order to access the ERG.			

Max Waiting Callers		
Possibility to set maximum number of callers allowed to wait in a ERG at the same time. This number should be set in accordance with the number of members answering the ERG calls (If this field is set to 4, only 4 callers will be allowed to enter the ERG. If caller number 5 tries to enter the ERG he will be transferred to 'Redirect Extension' number.		
Ring to Answer		
Possibility to set how many rings will be played to a caller before call enters the ERG. Values from 0 to 9 are available. If this value was set to 0, ERG music on hold will be heard as soon as call is connected.		
Record ERG Calls		
Possibility to record ERG Calls.		
Wake up Mobile Devices		
Possibility to select whether ERG should wake up mobile devices that are asleep or not.		
Members		
Possibility to add/manage ERG members.		
Name		
Possibility to add members name.		
Number		
Possibility to add number of the Extension on the system.		
Penalty		
Seting value within penalty (per member) allows defining priority which the system will use when sending calls to members. Values from 0 to 10 are available where 0 means highest priority and 10 means the lowest priority. If the strategy is defined as 'ringall', then only those available members with the lowest priorities will ring. If the Extension does not pick up it will not automatically go to the next Extension. It will keep ringing until it is picked up. It will only go to the next extension if the current extension is either busy or unavailable.		

Type		
Possibility to define member type (e.g. SIP).		
Search		
Possibility to filter records within members using search phrase.		
Move up/down/remove member		
Possibility to move up, move down or remove member.		
Music on Hold		
Possibility to select Music on Hold class name within all sound files belonging to this MoH class will be played to users in ERG in the background after user enters the ERG and the greeting message is heard.		
Replace Caller ID		
Possibility to replace Caller ID with the custom value for example, if 'Lobby - %CALLERID%' was typed, the caller id information as 'Lobby - 5552879' will be displayed where 5552879 is the actual number calling in.		
Language		
Possibility to define custom language for all sound files played by the ERG.		
ERG URL		
Possibility to send URL to Member's softphone so that softphone (in case of supporting this option) can open the URL and that Member can see callers additional info if available.		
Operation times		
Possibility to set the ERG open/closed times. Depending on the time when call is received, the call can be redirected to different PBX ware destinations.		
CSV Upload, CSV Download, Download CSV Template		
Possibility to upload Operations Time configuration from csv file, possibility to download current Operations Time configuration to csv file as well as possiblity to download template of Operations Time configuration to csv file.		

Inherit Operation times		
The Inherit option will allow administrators to simply put the Higher Level Operation Times settings back into effect if deemed necessary.		
Default Destination		
Possibility to redirect all calls to defined default destination which is PBXware during the closed time hours.		
Is Voicemail		
Possibility to redirect all calls to voicemail during the closed time hours.		
Greeting		
Possibility to set greeting sound file to be played to callers during the closed times.		
Closed Dates		
Possibility to sets the specific date/s when all calls are redirected to the 'Default Destination'. If the 'Destination' field in the Closed dates is set, calls will not go to the 'Default Destination' but to this number.		
Custom Destinations		
Possibility to redirects all calls received during set hours to the PBXware extension provided here.		
Open dates		
Possibility to sets the working hours during which DID is to redirect calls as set in DID Add/Edit window. If any call is received during the hours not set here, 'Custom Destination' are checked, and if they do not apply, the call is redirected to 'Default Destination' (Closed dates).		
Enhanced Ring Group Full: Redirect Destination		
Possibility to set extension number to which new users will redirected if ERG already accepted a maximum number of users.		
Enhanced Ring Group Full: Redirect to Voicemail		
Possibility to set a voicemail as redirect destination if ERG already accepted a maximum number of users.		

Announce Frequency		
Possibility to define will the hold-time announcement message be played, and if yes, how often (time in seconds).		
(If this option is set to '0', the announce message will not be played and if this field is set to 30, a single caller waiting in an ERG will hear 'Your call is now first in line and will be answered by the next available representative. Thank you for your patience.' message every 30 seconds.		
Min. Announce Frequency		
Possibility to specify the minimum amount of time that must pass before the caller's position in an ERG is announced again. This is used when the caller's position may change frequently, to prevent the caller from hearing multiple updates in a short period of time. Default value is 15 seconds.		
Announce Round Seconds		
Possibility to define rounding level for hold-time announcements. If this is set to 0, only minutes, not seconds, are announced; other possible values are 0, 5, 10, 15, 20 and 30.		
(E.g. When set to 30, a wait time of 2:34 will be rounded to 2:30.)		
Periodic Announcements: Periodic Announce		
Possibility to select the sound file that will be played periodically to callers waiting in an ERG. Suppored file name format have to be considerede - 'periodic-announce-\$NAME.gsm'.		
Periodic Announcements: Periodic Announce Frequency		
Possibility to specify time interval in seconds at which the periodic message will be played. E.g. If this field is set to 30, all callers waiting in an ERG will hear the 'Periodic Announce' message every 30 seconds, as long as they stay in the ERG.		
Periodic Announcements: First Periodic Announce Delay		
Possibility to specify the minimum number of seconds between position announcements. Default value is 15 seconds.		

Marshara Cattings, Ctatia Marshara Lagin		
Members Settings: Static Members Login Possibility to define whether to enable Static Members Login which means that Static Members would have to log in/log off manually to start/stop receiving calls. To log in/log off to all ERGs that an Extension is a member of or to log in to specific ERG and receives calls only from that ERG, defined access codes need to be entered. If the system is restarted or if it crashes, all Static Members will be logged in successfully upon successful system start. If a Static Member is logged in, s(he) can be added to an ERG through the GUI and start receiving calls from that specific ERG, or conversely, deleted from the ERG to stop receiving calls from that specific ERG. If this option is enabled, reordering of Members and penalty configuration will not work.		
Members Settings: Disable Member Enhanced Services		
Possibility to disable Member Enhanced Services which means that Enhanced services that are enabled on the Extension (that are ERG members) will possibly not be applied if an ERG call is passed to them. Enabling this may cause issues with Statistics.		
Ring Strategies		
Possibility to set the strategy/way calls are transferred to ERG members answering the calls.		
Ring Strategies: ringall	_	
Ring all available Members until one answers (default).		
Ring Strategies: linear		
When used with members, the members will be rung in the order in which they are ordered in the GUI. If the 'Static Member Login' option is set to 'Yes', they will ring in the order in which they were logged in.		
Ring Strategies: leastrecent		
Rings the interface that least recently received a call. In a ERG where there are many calls of roughly the same duration, this can work. It does not work as well if a member has been on a call for an hour, and their colleagues all got their last calls 30 minutes ago because the Member who just finished the 60-minute call will get the next one.		

Ring Strategies: random		
Rings a random interface. This actually can work very well and end up being very fair in terms of evenly distributing calls among members.		
Ring Strategies: rrordered		
Same as rrmemory, except the ERG member order from the config file is preserved so interfaces will ring in the order specified in this configuration file. If you use members, the members will be rung in the order in which they were added.		
Member Ring Timeout (sec)		
Possibility to set the Member's ring timeout.		
Autofill		
Possibility to define should callers be served one by one or in parallel fashion. With this option turned 'Off', even if there are five members available, calls will not be transferred to them until the first caller waiting in an ERG is connected to the member. When the first caller gets served, caller number two gets served and all others keep waiting. It is recommended to keep this feature always turned 'On' so callers can be served in order.		
Ring Members in Use		
Possibility to set whether members in use/active conversation should be called when a new caller comes into the ERG.		
Retry All Timeout		
Possibility to set for how long to wait before trying the ERG member again (time interval in seconds).		
Ring Strategies: Timeout Restart		
If this option is set to yes and a BUSY or CONGESTION signal is received on the line, the Member's timeout for answering will be reset.		
Ring Strategies: Wrap-up Time (sec)		
Possibility how long to wait (time interval in seconds) before sending a new call to a potentially free member, after successfully finished call.		

Incoming Options		
Possibility to set advanced ERG options t - allow the called user to transfer the calling user		
T - allow the calling user to transfer the call		
H - allow the caller to hang up by pressing *		
n - no retries on the timeout; will exit ERGs and go to the next step		
r - ring instead of playing MOH		
C - avoid missed calls in ringall strategy		
w - Instant Recording with Monitor		
x - Instant Recording with MixMonitor		
Ring ('r') timeout		
When 'r' is selected as Incoming Options and this timeout is used, ERG will first ring entered number of seconds after which MOH will start.		
Exit Digit: Use Exit Digit		
Possibility to define should users be able to exit the ERG by dialing a single digit and be automatically redirected to a preset PBXware destination.		
Exit Digit: Exit Digit		
Possibility to define the exit digit here. Once this digit is dialed by the user waiting in ERG, it will transfer the call directly to the set 'Destination'.		
Exit Digit: Activate Callback		
Possibility to define whether callback should be activated on Exit Digit.		
Exit Digit: Destination Groups		
Possibility to define local PBXware destination number that is dialed once the 'Exit Digit' is dialed.		
Exit Digit: Is voicemail		
Possibility to set whether the exit digit destination is pointing to voicemail.		

Abandoned Calls Notification: Enable Notification			
Possibility to enable or disable Abandoned Calls Notification feature			
Abandoned Calls Notification: Notification E-mail address			
Possibility to define the e-mail address which will receive notifications of abandoned calls, where an abandoned call is one where the caller hangs up the call while waiting to be answered.			
Enhanced Ring Groups Statistics			
Enhanced Ring Group Statistics represents a set of statistical reports which enable the selection of a date / time interval and desired members and Enhanced Ring Groups or all and different reports on all, answered, unanswered calls, member missed calls and repeated callers.	business	contact center	multi tenant
Filters			
When using regular filter options, users can filter reports by date range, Enhanced Ring Groups and members. In the case of using advanced filtering options, the user is able to filter reports by call duration, hold duration and caller using different time format. Filters are also used to select reports that user needs to be shown with possibility to previously filter type of reports: summary, member and Enhanced Ring Groups. This report(s) will then be moved to the 'Selected reports' section. By clicking the 'Show' button, the selected reports will appear in a new window.			
All Answered Calls			
This report provides an overview of all answered calls, talk time, hold time and all answered calls dispositions. Talk time and contains information such as Total duration of all answered calls, Min - Minimum duration of a single answered call, Max - Maximum duration of a single answered call and Mean - Average talk time value for all answered calls while Hold time contains information such as Total duration of hold time for all answered calls, Min - Minimum hold time for a single answered call, Max - Maximum hold time for a single answered call and Mean - Average hold time for all answered calls. All Answered Calls Disposition contains information such as number and percentage of Member Hangups, Caller Hangups, Transfered and Unqualified.			

All calls report offers an overview of all calls that have occurred on the system and all calls disposition. All calls contains information such as Talk time (Total, Min, Max and Mean) and Hold time (Total, Min, Max and Mean). All Calls Disposition contains information such as number of total calls as well as number and percentage of answered and unanswered calls.		
All Unanswered calls		
This report provides an overview of hold time within all unanswered calls and all unanswered calls disposition. Hold time within All unanswered calls hold time shows total hold time for all unanswered calls and average value of hold time for all unanswered calls. All unanswered calls disposition shows total calls, number and percentage of abondened calls, exited calls with key, call that were not answered within defined period of time and calls that were unqualified.		
Member Calls Per Enhanced Ring Group		
This report provides an overview of all calls on the system per Member and ERG with additional information such as: number and percentage of calls, talk time (total, min and mean delay) and number and percentage of hangups by caller or member and transferred calls.		
Member missed calls		
This report provides an overview of all missed calls on the system per Member with additional information such as: total, mean and average time of ringing before the call stopped ringing.		
Repeated callers		
This report provides an overview of number of repeated calls per Caller ID with additional information such as talk time (total, min, max and mean) and hold time (total, min, max and mean).		

Recordings under ERG statistics			
User now can access call recordings through ERG statistics under; All answered calls details, All answered calls dispositions, All calls, All calls dispositions, Member calls per ERG and Member missed calls breakdown. It can be done by clicking on Call ID which has a REC mark next to it which will be shown if the recording is available both locally or offloaded (removed from the system). By clicking on Caller ID which has a REC mark next to it, the new window will be opened where a report is shown for that single call and recording can be played for both local and offloaded recordings.			
Trunks/Gateways			
	business	contact center	multi tenan
Protocols: SIP, IAX2, DAHDI			
PBXware Trunks/Gateways supports SIP and IAX2 protocols as well as DAHDI interface technology.			
DAHDI Signalling: PRI, BRI, Analog			
PBXware Trunks/Gateways supports SIP and IAX2 protocols as well as DAHDI interface technology.			
BRI			
Removed BRI cards.			
Codec selection			
Every trunk on PBXware can have separate codec selection so you can make sure only allowed codecs are in use when call is passing through that trunk. Supported codecs:			

G.711 ulaw, G.711 alaw, G.722, G.723.1, G.726, G.726 AAL2, G.729, GSM, iLBC, Speex,

LPC10, H.261 Video, H.263 Video, H.263+ Video, H.264 Video.

Trunks on PBXware support SIP and IAX2 outbound registration.

SIP and IAX2 outbound registrations

DAHDI hardware supported: Digium Analog and Digital cards		
PBXware supports Digium Analog and Digital PCI cards:TDM10B, TDM11B, TDM12B, TDM13B, TDM20B, TDM21B, TDM22B, TDM23B, TDM2400P, TDM30B, TDM40B, TDM410P, TDM800P.		
DAHDI hardware supported: Sangoma Analog and Digital cards		
PBXware supports Sangoma Analog and Digital PCI cards, A500, B700, A200, A400, A601, A700, AFT-B600.		
DAHDI hardware supported: OpenVox Analog and Digital cards		
PBXware supports OpenVox Analog and Digital PCI cards: A400P/E, A400M, A810P/E, A800P/E, A1200P/E, A1610P/E, A2400P/E, D830P/E, D430P/E, D230P/E, D130P/E, D410P/E, D210P/E, D110P/E.		
DAHDI hardware supported: Xorcom Astribank		
Support for Xorcom Astribank VoIP gateway.		
DAHDI hardware supported: Woomera		
Removed Woomera devices completely.		
Check for Additional Headers		
This field should have a comma separated list of Headers to look out for. If a call comes to a trunk and has a header set that is in this list then that header will be preserved for when call leaves the system.		
Privacy for PAI header		
With the PBXware 6.3 version, users can select privacy for a PAI header from the drop-down menu on Trunks in the CallerID section. The options are as follows: 'None', 'Anonymous', 'Anonymous with Privacy ID', 'Anonymous with number', and 'Anonymous with number and Privacy ID'.		
SIP Response for non-existing DIDs		
Added an option to select a SIP response if a DID does not exist on the system.		

SIP Transports supported			
	business	contact center	multi tenant
UDP			
PBXware supports UDP transport. With UDP, computer applications can send messages, in this case referred to as datagrams, to other hosts on an Internet Protocol (IP) network without prior communications to set up special transmission channels or data paths.			
TCP			
PBXware supports TCP transport. TCP provides reliable, ordered, error-checked delivery of a stream of octets between programs running on computers connected to local networks or the public Internet.			
TLS			
PBXware supports SIP/TLS transport but it is important that clients also support TLS and that they are set up accordingly. TLS is cryptographic protocol and it provides encrypted communication over the Internet improving security.			
Customizing TLS Bind Port			
This port overrides any TCP/UDP settings in SIP protocol settings and applies for all users (external and internal).			
SIP General Settings			
	business	contact center	multi tenant
NAT settings			
PBXware NAT settings allow you to configure settings according to network configuration on location from which devices are registering to PBXware.			
Registrations			
Administrator can customize SIP registration settings to preffered values. It is possible to change settings for Length of incoming and outgoing registrations, Registration context, Registration timeout etc.			

Codecs		
PBXware supports number of different codecs: G.711 ulaw, G.711 alaw, G.722, G.723.1, G.726, G.726 AAL2, G.729, GSM, iLBC, Speex, LPC10, H.261 Video, H.263 Video, H.264 Video.		
Codecs (5.0 update)		
On top of the codecs mentioned above in PBXware 5 we are introducing Opus, codec that supports variable frame durations which can be changed on the fly allowing application to provide great voice quality even under less than perfect conditions.		
In addition, since patent for G.729 codec has expired, PBXware should also have Royalty Free G.729 licenses included on the system, so customers that would like to use G.729 will no longer have to purchase the licenses.		
RTP timers		
RTP timers define time period after which calls will be terminated if there is no RTP activity.		
SIP timers		
There are three SIP timer parameters on PBXware:		
 Minimum roundtrip time for monitored host that defines minimum rountrip time for messages to monitored host (default 100 ms). Default T1 timer is the estimated round trip time of an IP packet. By default, T1 is set to 500 milliseconds Call Setup Timer - this timer defines period after which call will autocongest if response was not received. Default value is 64 * [T1 timer] 		
MWI		
Message Waiting Indicator (MWI) is a feature that inform users that they have a new voicemail message(s) waiting in their mailbox. In its most common form, this feature lights a lamp on a phone to indicate the presence of a new or voice message.		

Subscriptions SIP protocol includes a standardised mechanism to allow any SIP client, for example your deskphone, to monitor the state of another device. So for example, if you would like to monitor wheter your coworker is on the phone or not, your phone must send SUBSCRIBE request, either directly to your coworkers deskphone or to a server that is aware of the state of his device. If the SUBSCRIBE request is successful, then every time that device changes state, your deskphone will receive a SIP NOTIFY message telling it about the event or change of status. This is the mechanism that IP phones use to control BLF lamps. PBXware enables you to make changes to subscription settings. You can use Allow Subscription setting to disable/enable subscription support, you can set specific context for SUBSCRIBE requests with Subscribe Context. enable disable Notify on RINGING or Notify on HOLD.		
Video support		
PBXware natively support SIP video but in order to use it some settings will need to be enabled on extension settingspage as well as on the device itself.		
Remote-Party-ID		
PBXware supports SIP Remote-Party-ID (RPID) allows you to use services like Caller ID and Caller ID blocking. Not setting RPID on your server in some situations can cause preferred Caller ID not to be delivered to called party (in which case default Caller ID assigned by your provider might be used instead) and it can also prevent you from hiding your Caller ID if necessary. This however, will mostly depend on your providers requirements.		
SIP Debugging		
SIP debugging features available in shell and Asterisk CLI are adding additional layer of information necessary for troubleshooting, when data available in CLIRs is simply not containing all the necessary information. To fully utilize these features user will require advanced experience with PBXware and Asterisk.		

QoS settings on PBXware allow administrators to prioritize traffic in their local network, improving call quality in busy and networks with low Internet bandwidth. In order for this to work, This feature is not set only on PBXware and QoS rules must be set up on networking devices on location phones are registering from.			
Codecs			
Codecs are used to convert an analog voice signal to digitally encoded version. Codecs vary in the sound quality, the bandwidth required, computational requirements, etc.	business	contact center	multi tenant
G.711 uLAW			
Support for G.711 uLAW codec.			
G.711 aLAW			
Support for G.711 aLAW codec.			
G.729			
Support for G.729 codec.			
G.729 - Royalty free			
Support for G.729 - Royalty free (License included with PBXware 5.0).			
G.722			
Support for G.722 codec.			
G.723.1			
Support for G.723.1 codec.			
G.726			
Support for G.726 codec.			
GSM			
Support for GSM codec.			
iLBC			
Support for iLBC codec.			

Speex			
Support for Speex codec.			
LPC10			
Support for LPC10 codec.			
H.261 Video			
Support for H.261 Video codec.			
H.263 Video			
Support for H.263 Video codec.			
H.263+ Video			
Support for H.263+ Video codec.			
H.264 Video			
Support for H.264 Video codec.			
Opus			
Support for Opus codec.			
Default codecs for newly created tenants			
When creating a new tenant the Codecs set will be inherited from Master Tenant instead of being hardcoded.	0	0	
Online Self Care			
Online Self Care portal allows end user to modify their extensions settings according to assigned permissions. Users can edit Enhanced Services settings, set up voicemail behavior, check CDRs, download call recordings etc.	business	contact center	multi tenant
Dashboard			
PBXware, the new OSC portal also has a Dashboard that displays all the relevant information about users calls for that day. On the dashboard, users can see their voicemail status, the total number of calls, the number of answered calls, talk time, and funds spent. In addition, the status for Call Forwarding and Do Not Disturb services is displayed, to help prevent scenarios in which users forget to disable these services, causing their calls to be forwarded or rejected.			

Destinations Permissions			
If permitted by assigned Service Plan users can edit their Destinations Permissions from Online Self Care portal.			
Registered Devices			
With multiple registrations available, users can also see what devices are registered to their extension and from which IP address. We combined geo IP lookup with this feature, so if the device is registering from a public IP address, a flag icon will appear next to the registered device name, representing the country in which that particular IP is located. This should help users to notice and report any unusual registrations to their extensions.			
Today's Calls			
the total number of calls, the number of answered calls, talk time, and funds spent.			
DIDs			
	business	contact center	multi tenant
CSV Upload			
CSV upload in DIDs page allow you to create large number of DIDs by simply uploading .csv file with DID numbers and preferred settings.			
CSV Download			
CSV Download in DIDs page allow you to download full .csv file with DID list and its defined settings.			
DID Groups			
To make DID management easier Multi-Tenant DID section has new feature for master administrator users. When the DID mode is set to "groups" (under master tenant settings), the administrator can assign a range of DID numbers to a DID group which can later be assigned to a particular tenant. The tenant administrator can later distribute and set up DID numbers from this group however preferred (single DID or a range of numbers) without needing PBXware administrator assistance as was the case in previous versions.	0		

Available numbers for a DID Group The DID Mode needs to be set to Group. When adding/editing a DID the following things have been changed: 1. After you choose a group, the DID/Channel field will be changed to a drop-down, depending on some rules (written under) 2. The dropdown will be used as an autocomplete feature and will show available DIDs from the chosen group 3. A maximum of 10 DID numbers are shown at a time so to narrow your choice you need to type in more characters 4. The drop-down will show only available DIDs, meaning that those already reserved/created will not be shown		
Enable / Disable local DID matching		
Forces the call to leave the system without trying to match a dialed number with a local DID. Option available only on master tenant/server.		
SMS Enabled		
The SMS feature allows for DIDs from PBXware to be used with the SMS service as well.		
Destinations: Extension		
Assigning Extension as a destination for DID will allow administrator to forward calls directly to specific extensions.		
Destinations: Ring Group		
Assigning Ring Group as a destination for DID will allow administrator to forward calls directly to specific Ring Group.		
Destinations: Multi-User Extension (DID Forwarding)		
Multi-User Extension is used for DID forwarding, in cases where remote system trunk is registering to PBXware extension, which allows PBXware to pass inbound calls to remote PBX system.		
Destinations: Multi User DID Controlled by license		
Multi User on DID are now controlled by license.		

Destinations: IVR		
Setting IVR (Interactive Voice Response) as a DID destination will enable callers to choose one of multiple available selections by entering assigned number on their phone keypad.		
Destinations: Queue		
When set as a PBXware destination calls will be forwarded to Queue where they will wait, listening Music on Hold and/or pre-recorded announcements, until they are served by available Queue member.		
Destinations: Voicemail		
If preferred DID calls can be forwarded to extensions voicemail directly, even if user is available.		
Destinations: Conference		
Setting Conference room number as a DID destination will allow callers outside the company to join conference calls by dialing DID number.		
Destinations: Remote Access		
Remote Access can be set as a DID destination to allow users to make calls from their extension even when they are not in the office. When user dials DID number set to use Remote Access he will be asked to enter extension number and PIN. Once user is authenticated he can make calls to allowed destinations, check voicemail or even log in as queue agent.		
Destinations: Use PBD pin as DID remote access authentication		
Users can choose PBD authentications for DID remote access.		
Destinations: Trunk		
When trunk is set as a DID destination PBX ware will act as a gateway and it will simply pass the calls to remote system through specified trunk, where it will be routed accordingly.		0

Destinations: Fax to E-mail		
Set Fax to E-mail as a DID destination if you would like to receive faxes on PBXware. Fax will be sent to e-mail address (if SMTP server is configured on PBXware) and saved on PBXware where it can be downloaded from FAX section.		
Destinations: External Number		
You can set External Number as a destination to forward the calls to numbers that are not terminating on PBXware, for example users cell phone number.		
Destinations: Phone Callback		
Setting Phone Callback as DID destination allows users to make calls from remote locations through PBXware without being charged. If user calls a number which is configured as a DID on the system, system will match users caller ID, hang up and call the user back, prompting for the destination to be called. This option requires additional settings in Phone Callback Enhanced Service.		
Destinations: Deny Access		
When used, Deny Access destination plays a busy sound to all the callers that dial that DID number.		
Operation Times		
Operation times is feature that enables you to forward DID calls to a destination different from the one that is set in DID, based on date, day and time.		
Caller ID Validation & Routing		
This option is used to fine tune functionality of the DID by adding rules according to which calls will be routed preferred destinations based on the rule associated with specific Caller ID.		
Custom Ringtones		
Custom ringtones feature allows you to set up your DID so your phone use a different ringing sound when calls are routed to your phone from specific DID.		

Caller ID Replacement		
Allows you to append preferred string to incoming caller ID number in order to distinguish calls coming from specific DID from every other call.		
Call Recording		
Call recording can be enabled on DID as well as on several other places on PBXware, however, If enabled on DID, call recording will have entire length of the call in a single sound fie, even if call was transfered more than once.		
Queue Priority		
Queue priority option allows you to assign certain level of priority for calls that are being forwarded to Queue. Set up a queue priority level to give calls higher or lower priority compared to calls entering the queue from other destinations.		
Billing: Specific Service Plan		
Creating multiple service plans enables you to easily assign or change call prices which will be used by all extensions that are set with specific service plans. Creating multiple Service Plans allow you to set up extension pricing based on the package you are selling to that particular user or group of users. In addition to this, Service Plan allows you to create a template with specific set of Enhanced Services and/or Destinations permissions which will be enabled for extensions that are assigned with particular service plans, preventing manual labor which would be needed if every extension was to be set manually.		
Billing: Use Billing Extension for Billing		
You can eassily manage inbound calls billing on DIDs by assigning Billing Extension number, automatically deduct the funds from extensions account balance for every inbound call made.		
Billing: Force codec		
Enables you to force specific codec to be used for all calls that come to the DID this feature is enabled on.		

Billing: Strip Digits			
If your calls are being directed to a trunk, it is possible to define number of digits which will be stripped from the beginning of the incoming call number in order to meet the dialing rules specific to that trunk provider.			
Billing: DID Name field			
Added the 'Name' field to the DID page.			
Caller ID Validation & Routing			
This option is used to fine tune functionality of the DID by adding rules which route the calls to different destinations based on incoming Caller ID.	business	contact center	multi tenant
Match Explicitly			
Match Explicitly will inform the system to explicitly match the numbers with identical Caller ID as stated. For example, if you would like to block particular number you would enter that number, select block and set Match Explicitly to yes. This will ensure only entered number is blocked once it reach the DID.			
Match Partially			
This option will inform the system to match all the Caller IDs that starts with specific number. For example, if you are receiving calls from range of numbers originating from a foreign country you would like to block, you could enter starting digits that are in common for all the Caller IDs you were receiving nuisance calls from. This will prevent all the calls from that particular range to be block or forwarded, depending on your preference. NOTE: Unless you would like to block all the inbound calls originating from a specific country, try to extend the range of numbers to at least cover area code alongside country code to minimize the range you are trying to block.			
Custom Destinations identical to DID Destinations			
Destinations used for Caller ID Validation and Routing can be set to same values available on DIDs.			

CLI validation & routing per tenant			
CLI Routing and validation per tenant (the tenant administrator can manage the	0	0	
validation and routing per tenant). This option is used to fine-tune the functionality by adding rules which send the calls to different destinations based on Caller IDs.			
Conferencing			
	business	contact center	multi tenant
Limit maximum number of participants			
Allows you to define maximum number of users that can join the conference.			
Instant conferences via Desktop App			
Integration with gloCOM allows you to create Instant conferences by draging users into an active call.			
Conference PIN			
Enables you to define Conference PIN all users must enter in order to join conference.			
Conference Admin PIN			
Enables you to define Conference Admin PIN to authenticate user as a Conference Admin in order to assigns administrative privileges.			
Conference Marked User PIN			
Enables you to define Conference Marked User PIN to authenticate user as a Marked user in order to assign set of privileges.			
Announce user join/leave			
When joining new conference members will be asked to say their name and press the '#' key before they enter the conference, name will be recorded and played to other			
conference members when a caller joins/leaves the conference.			
Announce number of participants			
Turning on this option will announces the number of conference participants to a new conference member. "There is currently one other participant in the conference."			

Email conference recording		
At the end of a conference call (static not dynamic) if the email is in there as an option the sound file of the conference would be emailed to a pre-specified email once everyone has exited the room.		
DTMF menu for participants: Mute Control		
Conference Admins are able to mute specific user.		
DTMF menu for participants: Volume Control		
Conference Admins are able to adjust speaking volume for entire conference room.		
DTMF menu for participants: Kick Users		
Conference Admins are able to kick specific user(s) from conference room.		
DTMF menu for participants: Eject users		
Conference Admins are able to use eject command to kick last user that joined the conference room.		
DTMF menu for participants: Lock conference		
Conference Admins are able to lock the conference room, preventing new callers from joining in.		
DTMF menu for participants: Record conferences		
Enables recording of conference room calls.		
DTMF menu for participants: Music on Hold		
This option will play Music on Hold to a first user that joins the conference. As soon as second user enters conference room Music on Hold stops playing and users are able to talk to each other.		
DTMF menu for participants: Wait for Marked User to start conference		
Enabling this option will prevent users to talk to each other until marked user join the conference, this is useful when you are arranging a conference call between multiple parties that are unfamiliar with each other.		

Destinations: Close the conference when Marked User leaves		
Closes the conference when last marked user exits, regardless of number of active participants in the conference room, their calls will be immediately dropped at that moment.		
Destinations: Control members of conference		
Conference admin is able to mute, add or remove conference participants.		
Control options for each member: Admin		
If this option is enabled, conference calls coming from the extension will be treated with admin privileges.		
Control options for each member: Marked		
If this option is enabled, conference calls coming from the extension will be given less privileges than admin, but more than regular conference participants.		
Control options for each member: Talk-Only		
If this option is enabled, conference calls coming from this extension will be allowed to talk only and no sound from the conference will be heard on that phone.		
Control options for each member: Listen-Only		
If this option is enabled, conference calls coming from this extension will be allowed to listen only and no sound from the extension will be heard in the conference.		
Control options for each member: Exit Digit		
If this option is enabled, users will be allowed to exit the conference by dialing any digit on their phone.		
Control options for each member		
Added the possibility for administrators to change Conference PIN even when they do not have the 'Show Advanced' toggle button enabled.		

IVRs			
	business	contact center	multi tenant
IVR Type: Standard IVR			
IVR (Interactive Voice Response) is automated answering machine which guide callers to their destination by providing a number of choices and waiting for caller to make a selection through DTMF tones via device keypad.			
IVR Type: Pin-based IVR			
PIN-based IVR allows dialing local/remote destinations by providing a pre-set IVR PIN number.			
IVR Type: Multi-digit IVR			
Unlike regular IVR, Multi-digit IVRs accepts two or more digits as a response from caller, therefore providing a wider range of options compared to Standard IVR.			
IVR Type: Meeting IVR			
Meeting IVR is selected when a user wants to join the Conference only via audio. A user needs to call a DID that is connected to a Meeting IVR and follow the instructions in order to join a Meeting. The necessary information (Meeting Number and Participant ID) is provided in an e-mail when the Meeting is being created.			
IVR Type: IVR Tree Builder			
IVR Tree is a special form of IVR where creation of a particular IVR is more graphically oriented than it is with regular IVRs. This allows better overview when creating more complex IVR system in which callers have to navigate through multiple IVRs in order to reach preferred destination.			
IVR Destinations: Extension			
Setting up extension as a destination in IVR will forward the call to specified extension number once assigned digit is pressed.			

IVR Destinations: IVR		
Setting up IVR as a destination in IVR will forward the call to specified IVR number once assigned digit is pressed.		
IVR Destinations: Queue		
Setting up Queue as a destination in IVR will forward the call to specified Queue number once assigned digit is pressed.		
IVR Destinations: Conference		
Setting up Conference as a destination in IVR will forward the call to specified Conference number once assigned digit is pressed.		
IVR Destinations: Voicemail		
Setting up a Voicemail as a destination in IVR will forward the call to specified extension number voicemail directly, without dialing the extension, once assigned digit is pressed.		
IVR Destinations: Remote Access		
Set Remote Access as an IVR destination to enable users to dial into the system from remote location and authenticate to their personal extensions and make calls as if they picked up their office phone.		
IVR Destinations: Directory		
With this option selected, you will have the ability to dial an extension by entering the first three letters of the extension's last or first name.		
IVR Destinations: Fax to E-mail		
Set Fax to E-mail as an IVR destination if you would like to receive faxes on PBXware. Fax will be sent to e-mail address (if SMTP server is configured on PBXware) and saved on PBXware where it can be downloaded from FAX section.		
IVR Destinations: Call External Number		
In order to dial specific number as an IVR selection you must select Call External Number as a destination in IVR and enter the number which will be dialed once selection is made.		

IVR Destinations: Ring Group		
Setting up Ring Group as a destination in IVR will forward the call to specified Ring Group number once assigned digit is pressed.		
IVR Destinations: Remote Access		
Setting up Remote access as a destination in IVR will allow the caller to use Remote Access functionality.		
IVR Destinations: CRM Routing		
Setting up CRM Routing as a destination in IVR will allow the caller to use CRM Routing, which allows routing to a specific Queue or IVR or playing sound files based on information fetched from CRM.		
IVR Destinations Options: Default Caller ID		
You can append preferred string to incoming Caller ID (for example IVR 1) to diferentiate between multiple destination calls can come from.		
IVR Destinations Options: Change Language		
If sound files in language other than english are uploaded to PBXware alongside default english language prompts, you can set voice prompts to be played in preferred language once call is routed to its destination.		
IVR Destinations Options: Read extension number		
Specific for Directory destination.		
IVR Destinations Options: Search for name		
IVR Destinations Options: Department filter		
IVR Destinations Options: Exit digit		

Standard IVR Options: Operator Extension		
Operator extension option allows you to assign the number of extension to which calls will be redirected to if 'IVR Status' is set to 'Off'.		
Standard IVR Options: Custom timeouts		
Allows administrator to set preferred time values for Response Timeout, Digit Timeout, Selection Timeout etc. In case any of these timeouts is exceeded voice prompt will be played back to the user for several times, after which, call will be dropped.		
Standard IVR Options: Custom Greeting		
Custom greeting enables administrator to play a greeting with IVR instructions once caller gets to the IVR.		
Standard IVR Options: Change greeting access code for a specific destination type		
Users are able to change a greeting themselves without the admin making any changes to the file name and assign it to an IVR greeting. Two new access codes have been added: 1. Change Greeting: defaults to *303 and takes a queue/IVR or ring group as the destination. When dialed the user is prompted to record a new greeting. Once accepted the greeting is set as the destination's new greeting. 2. Change Greeting: defaults to *304 and takes a queue/IVR or ring group as the destination. When dialed the user is prompted to record a new greeting. Once accepted the greeting is set as the destination's new greeting, and the old greeting, if it existed, will be deleted.		
Standard IVR Options: IVR extension exclusion		
Anewfield under "IVR > Local Dialing" called "Exclude list" has been added. Any extension added in field cannot be called form that IVR even if it is within the set range.		
Standard IVR Options: IVR extension range		
When enabling local dialing on IVR, it is possible to exclude 1 or 2 extensions from this.		
Standard IVR Options: IVR: Add # Option		
Allow # to be used as an IVR option.		

Standard IVR Options: Ringing Type		
This option allows you to set whether you would like to play Music on Hold or ringing sound to callers once their call reach the IVR.		
Standard IVR Options: Dial Local Extensions directly		
This feature allows callers to dial extension number directly, once their call enters the IVR. If this feature is enabled anybody that enters the IVR will be able to dial extensions on the system/tenant directly if they know the number that would like to dial. This option can be used alongside standard IVR selections.		
Standard IVR Options: Dial Local Extensions limits		
Administrator is able to restrict extension dialing from IVR by defining range of extensions that are allowed to be called directly.		
Standard IVR Options: Dial Permissions		
Permissions are used to allow an organization to restrict who is able to enter an IVR. In particular, there are organizations where access to the IVR is only allowed to callers with a valid account number, but it can be used for other similar purposes.		
Standard IVR Options: Operation Times		
Operation times enables administrator to forward calls that are supposed to enter IVR to a different locations depending on date, day and time.		
Standard IVR Options: FAX Detection		
When FAX recognition is enabled on your PBX ware system, you can turn on FAX detection on your IVR by entering e-mail address in FAX Email field. This will automatically accept all FAX calls and send received FAXes to that e-mail address without any additional actions from sender.		
Standard IVR Options: Disable CallerID (PIN-based IVR only)		
This option disables CallerID but only for PIN-based IVRs.		

IVR Directory			
With this option selected, you will have the ability to dial an extension by entering the first three letters of the extension's last or first name.	business	contact center	multi tenant
Search by First Name			
With this option selected callers will have to enter starting letters of users first name in order to dial his extension. This is done by entering numbers that correspond with letters on the keypad on the phone/softphone caller is using.			
Directory DTMF timeout			
After entering directory from IVR for example, from that moment you only have 3 seconds to start typing in the first 3 letters of a last name if you do not do that call gets disconnected.			
Directory DTMF exit key can be customized			
The user can exit the Directory app at any moment by pressing the '#' or '0' key.			
Search by Last Name			
With this option selected callers will have to enter starting letters of users last name in order to dial his extension. This is done by entering numbers that correspond with letters on the keypad on the phone/softphone caller is using.			
Search by both First and Last Name			
With this option selected callers will have to enter starting letters of users First or Last name in order to dial his extension. This is done by entering numbers that correspond with letters on the keypad on the phone/softphone caller is using.			
Play Voicemail greeting for Name			
If name is recorded in voicemail box by user, message will be played in IVR directory instead automated spelling.			
IVR Directory filter per department			
This feature simplifies the search inside the IVR Directory by limiting searches to a group of extensions (departments) instead of the entire directory. This feature will assist when searching through the IVR if there are duplicate names in a sys-tem.			

IVR Tree			
Same as regular IVR, IVR tree offer multiple available options for destination type.	business	contact center	multi tenant
Available actions: Dial Local Extension			
Dial Local extension feature will allow you to assign a local extension as an IVR Tree destination.			
Available actions: Dial Remote Extension			
This feature allows you to assign an external number as an IVR Tree destination.			
Available actions: Dial Voicemail			
This feature allows you to assign an extension voicemail as an IVR Tree destination.			
Available actions: Check Voicemail			
Set up Check Voicemail on IVR Tree to allow users to log in to their extensions voicemail and check messages without using their extension.			
Available actions: Go to Context			
Setting Go to Context on IVR Tree will forward calls to given context and extension.			
Available actions: Start Recording			
Call recording will be enabled from point in which call gets to branch of IVR tree with Start recording enabled.			
Available actions: Set Queue Priority			
Queue priority option allows you to assign certain level of priority for calls that are being forwarded to Queue. Set up a queue priority level to give calls higher or lower priority compared to calls entering the queue from other destinations.			
Available actions: Set Language			
If sound files in language other than english are uploaded to PBXware alongside default english language prompts, it is possible to set voice prompts to be played in preferred language.			

Available actions: Play Sound		
This selection will play selected sound file in multiple languages (if available). In addition, it is possible to allow DTMF entries, enabling callers to dial local destinations.		
Available actions: Change Caller ID		
You can append preferred string to incoming Caller ID (for example IVR Tree 1) to diferentiate between multiple destination calls can come from.		
Available actions: Wait		
This option allows you to set pause time in seconds after which IVR will continue executing assigned actions actions.		
Available actions: Busy Signal		
When selected, this option will play Busy signal to callers.		
Available actions: Hangup		
This action will hang up incoming calls upon execution.		
Available selection destination type: Go to IVR Tree		
This option will forward calls to other IVR Tree destinations.		
Available selection destination type: Local/Remote Destinations		
IVR Tree supports forwarding calls to both Local and Remote destinations.		
Available selection destination type: Voicemail		
IVR Tree supports Voicemail as an IVR destination.		
Available selection destination type: Ring group		
IVR Tree supports Ring Group as an IVR destination.		
Available selection destination type: Queue		
IVR Tree supports Queue as an IVR destination.		

PIN based IVR			
PIN-based IVR allows dialing local/remote destinations by providing a pre-set IVR PIN number.	business	contact center	multi tenant
CSV upload			
PIN based IVR allows you to create a large number of PIN numbers and matching destinations by uploading .CSV file.			
Expiry date per PIN			
PIN Expiry date allows PBXware administrator to define PIN expiry date, rendering it unusable after specified date.			
Destination per PIN			
Every created PIN is assigned to specific destination, once pin is entered in PIN based IVR matching destination will be dialed.			
IVR Statistics			
We have added a new feature called IVR statistics, this feature is similar to Queue or Agent statistics for Call Center systems.	business	contact center	multi tenant
IVR calls			
IVR call statistics report will show: Callid, Date time, Called Number, Callerid, IVR name, IVR number, Option, Destination, Dest. Type, Ended.			0
IVR calls per called number			
IVR calls per called number report will show: Called Number, Date Time, Callerid, Callid, IVR name, IVR number, Option, Destination, Dest. Type, Ended.			0
IVR calls per option			
IVR calls per option: Callid, Date time, Called Number, Callerid, IVR name, IVR number, Option Destination, Dest. Type, Ended.			0
IVR calls per DID in IVR statistics	0		
IVR statistics page has been enriched with a new report page called "IVR calls per DID".	O		O

Available in Bussiness and MT edition			
Ported to the Multi-Tenant and the Business edition.			
Remote Access			
In most cases Remote Access is set as a DID destination (although it can be set as an IVR destination as well) in order to allow users to make calls from their extension even when they are not in the office. When user dials DID number set to use Remote Access he will be asked to enter extension number and PIN. Once user is authenticated he can make calls to allowed destinations, check voicemail or even log in as queue agent.	business	contact center	multi tenant
Destinations			
Set destination to Remote Access in order to allow users to log in to their extension and make calls from it as if they were using their deskphone.			
Voicemail			
Voicemail can be assigned as a Remote Access destination in order to allow users to check their voicemail when not in the office.			
Agent Login			
Voicemail can be assigned as a Remote Access destination in order to allow users to log in as agents even if they are not using PBXware extension.			
Operation Times			
Operation times is feature that enables you to forward IVR calls to different locations depending on date, day and time.	business	contact center	multi tenant
Default Destination			
Destination, different from the one set on IVR, where calls will be forwarded according to Operation Times rules.			
Custom Destinations for specific Day/Time Range			
You are able to define specific day/time range when calls will be forwarded to custom destination.			
Control Open Days and Hours			
You are able to define day/time range after which calls will be forwarded after working hours.			

Control Closed Dates and Hours			
You are able to define default destination where calls will be forwarded during closed dates.			
Custom Greeting			
Create custom greeting and assign it to Operation Times to inform customers that their call will be forwarded to a different destination because your office is closed.			
Midnight reset for Operation times			
In Access Codes → Edit, the Operation Times group feature called "Midnight reset" is available. By default this option is set to "Yes", meaning that the access codes will be reset in midnight. If set to "No", the midnight reset will be skipped.			
Import and export csv for operation times			
Operation Times configuration can be exported into csv or imported from csv file.			
Queues			
Queue system allows you to receive more calls in your PBXware than your staff members are able to answer at the same time.			
NOTE: Queues in MT edition have less options available. For example, Agents are not available on MT and only static members (SIP extension) can be added to queue members list.	business	contact center	multi tenant
Queue Ring Strategies			
Queue ring strategies allows you to distribute queue calls more efficiently and according to your specific needs. You can assign one of the available strategies to your queues in order to ring queue agents or static members randomly or in specific order.	0		0
Queue Ring Strategies: Ring All			
With Ring All ringing strategy selected, once call enters the queue it will ring all available queue members at the same time.			
Queue Ring Strategies: Linear			
When Linear ring strategy is selected, once call enters the queue it will ring available queue members one by one in a specific order.			

Queue Ring Strategies: Least recent			
Least Recent ring strategy will ring available agents with least answered calls in order to distribute the calls evenly between all queue members.			
Queue Ring Strategies: Fewest calls			
Fewest calls ring strategy will ring available agents with fewest calls received in order to distribut the calls evenly between all queue members.			
Queue Ring Strategies: Random			
Random ring strategy will randomly ring any of the available queue members.			
Queue Ring Strategies: Round-Robin with memory			
Round-Robin with memory ring strategy will ring available agents one by one but it will continue where it stopped the last time when call was answered.			
Queue Ring Strategies: Round-Robin ordered			
Same as Round-Robin with memory, except the queue member order from the config file is preserved so interfaces will ring in the order specified in the configuration file. If you use dynamic members, the members will be rung in the order in which they were added.	0	0	0
Queue Ring Strategies: Random with penalty			
Random with penalty ring strategy will randomly ring available members of the lowest penalty level. In case all the members of that penalty are busy or not available, call will move to members with higher penalty level assigned.			
Music on Hold			
This option allows you to enable music on hold for callers that are waiting in queue.			
Custom Ringtones			
PBXware allows you to set up your queues to send a matching string to the phone so it is informed to use a different ringtone when calls are coming from queue set up with this option. In order to use this feature, alongside PBXware part changes must be made in the phone as well. For information on how to set up the phone please consult your device admin manual.			

Caller ID Replacement		
Caller ID Replacement allows you to append preferred string to incoming caller ID number in order to distinguish calls coming from queue from other calls to extension, for example Queue 1.		
Custom Sounds		
You can record your custom sound files like Greeting, Periodic Announce, Agent Announce, Callback announcements for Caller and Agent etc.		
Ringing Timeouts		
Ring timeouts allow you to define how long will call ring each queue member before it continue to the next available member.		
Waiting Timeouts		
Define total time call can spend in queue and what should happen with unanswered calls and where they should be routed after timeout is reached.		
Announcements		
Queue Announcements inform callers waiting in queue what is their current position and for how long (approximately) they should wait before their call is answered.		
Periodic Announcements		
Periodic announcement option allows you to play custom message to the callers waiting in the queue.		
Call Recordings		
In order to allow you to preserve important customer calls PBXware queues also offer option to record all queue calls.		
Exit Digit		
This option allows you to define exit digit which will be used to allow users to drop out of queue call. Depending on queue settings they can be forwarded to an operator extension, voicemail or to initiate queue callback.		

Abandoned Calls E-mail Notification		
When Abandoned calls e-mail notification is enabled, PBXware will send reports, once per hour, with information on all abandoned queue calls and the reason why calls were dropped.		0
Queue Callback		
Depending on queue settings Queue Callback will initilize the call to numbers that dropped queue calls before they were served by Agents. Queue Callback have number of options that will allow you to fine tune it according to your personal preferrences.	0	0
Queue Callback IVR		
In addition to default Queue Callback setting that use Caller ID to initialize the call, Queue Callback IVR allow users to enter Different caller ID number from the one they are using.	0	0
Static Member Login		
Queues on PBXware bussiness edition offer option to allow static members (SIP extensions) to log in and log out of queue in same manner as Agents.		0
Prevention of Enhanced services for Static Members		
This option allows you to choose whether extensions Enhanced Services should apply to queue static members. The option is called Disable Member Enhanced Services. When set to Yes, ES rules will not be applied when the Queue dials static members.		
NOTE: This only applies to Static members with no login and Callback Agents or DynamicAgents that have ES disabled by default.		
Queue Members management		
You can easily add and remove queue members from queue members management panel.		

Queue Member Penalties		
Assigning different penalty levels to queue members will help you achieve more precise call distribution in your queues. Members with lower penalty number will receive calls until all members with that penalty are busy or unavailable, which will move call to members with higher penalty number.		
Desktop App Integration		
PBXware Call Center integration with desktop clients gloCOM Agent and gloCOM Supervisor will allow you to improve your employees performance by speeding up their workflow.		0
Caller ID for Queue Callback		
Caller ID for callback is a new queuing feature in our Call Center Edition. When a customer receives a call from Queue Callback you can choose a Caller ID to display. New option in queue which would disable this or enable per user preference is presented. Basically if user wish to pass abandoned calls to queue and still have these calls in statistics or if abandoned call during greeting should be detected and not routed to queue and shown in statistics.		
Caller early hangup		
When a call comes into the system via DID if a call is hangup while greeting on DID is played call still passes to the Queue because of statistics, so users are aware they had abandoned calls. New option in queue which would disable this or enable per user preference is presented. Basically if user wish to pass abandoned calls to queue and still have these calls in statistics or if abandoned call during greeting should be detected and not routed to queue and shown in statistics.		
Disabled queue calling to mobile endpoints in PBXware		
Disabled queue calling to mobile endpoints in PBXware.		
Limited number of members to ring for ringall strategy		
When strategy is "ringall", the default number of Queue Members and Agents that may be dialed in a single Queue is set to 9. The limitation number for a Queue can be changed per single Queue if additional configuration is set differently.		

Better control over announce			
Position and Periodic announces are split into separate sections. Also, we added option to choose if one want to hear Hold-Time or Position announce or both.			
Disable CDRs for unanswered calls from queue			
Ability to disable CDRs for unanswered calls to SIP members from queue.			
Inbound Dispositions			
Ability to set disposition for inbound calls.			
Skilled Based Routing (SBR)			
	business	contact center	multi tenant
RULES			
Different agents in queue can have different penalties. SBR allows one to create Sets of Rules to change the value of the Min Penalty and Max Penalty channel variables in mid-call. This means that it is possible to open a call to more members or potentially a different set of members. Agents with different penalties can answer a call in different period of time, depending on the Rule. On each queue one can choose which rule to use or no rule to use.			
Rule configuration			
Using this one can controll when Rule's configuration will be changed (Caller Hold Time) and which agents can answer the call (using Min and Max penalties).	0		0
Queue Monitoring			
Queue monitor is useful tool that will display information on Agent status (Unavailable, Idle, On call), and some Basic queue information (Answered calls, Abandoned calls, current number of calls waiting in queue etc.), or one can select specific queue to show detailed information about it.	business	contact center	multi tenant
Calls Waiting	0		\bigcirc
Queue monitor Calls Waiting section displays total number of calls waiting in queue.	O		O

Average Calls waiting Queue monitor Average Calls waiting section displays average time calls were waiting in queue.	0	0
Agents Logged		
Queue monitor Agents Logged section displays information on number of logged in agents.	0	0
Agents on Call		
Queue monitor Agents on Call section displays information on agents on call.	0	O
Agents Idle		
Queue monitor Agents Idle section displays information on number of idle agents.	0	O
Agents not logged		
Queue monitor Agents not logged section displays information on number of agents that are not logged in.	0	0
Agents Not Ready		
Queue monitor Agents Not Ready section displays information on number of agents that are in not ready state.	0	0
Overview		
Queue monitor Overview section displays information about number of Entered, Connected and Abbandoned calls for specific queue for current day.	0	0
Callers		
Queue monitor Callers section displays information about number of Total, Connected and Waiting callers for specific queue - realtime data.	0	0
Agents		
Queue monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific queue - realtime data.	0	0

0		0
0		0
	contact center	multi tenant
O		O
O		O
O		<u> </u>
<u> </u>		
0		
		O
		\bigcup
	business O	business contact center O O O O O O O O O O O O O O O O O O

Dialer			
Dialer allows lists of data to be loaded to a database and an application will run and dial these numbers based on an algorithm or settings entered by the admin. Dialer is mainly managed through Campaigns.	business	contact center	multi tenant
Dialer Ring Strategy: Power			
In the power strategy the campaign dials leads based on Idle agents multiplied with power number.	0		0
Dialer Ring Strategy: Preview			
This strategy gives an agent the ability to preview some details about a lead before it decides to dial them.	0		0
Dialer Ring Strategy: Progressive			
This strategy works the same as a preview strategy, the only difference is that the agent has a certain timeout in which he/she must perform a dial.	0		0
Dialer Ring Strategy: Voice Messaging			
This strategy automatically plays the message to leads. Additionally it records DTMF pressed during message.	0		0
Numbers	0		
Option to import list of numbers to call via csv files.			
Number of retries	\circ		
How many time campaign will try to call one lead (one number imported via csv file).			
Force Trunk and Codec	\circ		
Campaign can be forced to use only one Trunk and/or audio codec.			
Agents			
Agent can be member of only one campaign. Agents will not be able to use enhanced services when getting calls from dialer.	0		0

Retries No Answer/Busy/Abandon	_	
Time in which the campaign will try to call again if current lead disposition is No Answer/Busy/Abandon.	0	0
Answering Machine Detection		
Posibility to enable and configure AMD. If this feature is on, for each lead answer, dialer will run AMD, to avoid connecting agent with answering machine.	0	0
Campaign Cycle		
For power like strategies (Power and Voice Messaging), one can option to set number of seconds campaign will sleep bewteen cycles, maximum number of leads to call per cycle nad maximum number of concurrent leads campaign can have.	0	0
Caller ID		
Option to choose which caller ID campaign will use.		O
Dial Timeout	0	
Time dialer will ring the lead.		O
Miminum digits to dial	0	
A minimum number length allowed in order to dial numbers.		
Don't dial failed numbers again	0	
If the numbers have failed for some reason, set the dialer not to dial them again.		O
Generate CDR		
Option to enable/disable dialer to generate Asterisk CDR entries. Turning this feature ON is a performance penalty, and should be used only if you want to debug trunks.	0	0
Operation Times		
This feature allows one to set working time for campaign, and applies only for power like strategies.	0	0
Dispositions		
One can create list of dispositions that Agent will see in gloCOM which can be applied at the end of the call.	0	0

Desktop App Integration PBXware Contact Center integration with desktop clients gloCOM Agent and gloCOM Supervisor will allow you to improve your employees performance by speeding up their workflow.			0
Stop Campaign(s)			
Option to stop specific campaign or to stop all campaigns at once.	O		O
Campaigns Monitoring			
Campaign monitor is useful tool that will display information on Agent status (Loggend, Paused, Idle, Busy), and some basic campaign information (number of Dialling calls, number of Connecting calls, number of Connected calls), or one can select specific campaign to show detailed information about it.		contact center	multi tenant
Calls Dialling			
Campaign monitor Calls Connection section displays number of calls currently dialing.	O		O
Calls Connecting			
Campaign monitor Calls Connection section displays number of calls currently connecting.	0		0
Calls Connected			
Campaign monitor Calls Connected section displays number of calls currently connected.	0		0
Agents Logged			
Campaign monitor Agents Logged section displays information on number of logged in agents.	0		0
Agents Paused			
Campaign monitor Agents on Call section displays information about paused agents.	O		O
Agents Idle			
Campaign monitor Agents Idle section displays information on number of idle agents.	0		O

Agents Busy Campaign monitor Agents Busy section displays information on number of agents that are busy. Contacts Total Number of contacts made by agents on campaign. Contacts Rate Rate of contacts on campaign. Overview Campaign monitor Overview section displays information about number of Dialed, Unanswered, Connected and Abbandoned calls for specific campaign for current day. Leads Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign - realtime data. Agents Campaign monitor Agents section displays information about number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC Numbers DNC Numbers DNC Numbers centain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible numbers centain a list of numbers marked as DNC via csv file.				
Number of contacts made by agents on campaign. Contacts Rate Rate of contacts on campaign. Overview Campaign monitor Overview section displays information about number of Dialed, Unanswered, Connected and Abbandoned calls for specific campaign for current day. Leads Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign - realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call Numbers contain a list of numbers not to be dialed by agent, You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Campaign monitor Agents Busy section displays information on number of agents that	0		0
Number of contacts made by agents on campaign. Contacts Rate Rate of contacts on campaign. Overview Campaign monitor Overview section displays information about number of Dialed, Unanswered, Connected and Abbandoned calls for specific campaign for current day. Leads Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign - realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Contacts Total			
Rate of contacts on campaign. Overview Campaign monitor Overview section displays information about number of Dialed, Unanswered, Connected and Abbandoned calls for specific campaign for current day. Leads Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign - realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Number of contacts made by agents on campaign.	O		O
Rate of contacts on campaign. Overview Campaign monitor Overview section displays information about number of Dialed, Unanswered, Connected and Abbandoned calls for specific campaign for current day. Leads Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign – realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign – realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Contacts Rate	\bigcirc		
Campaign monitor Overview section displays information about number of Dialed, Unanswered, Connected and Abbandoned calls for specific campaign for current day. Leads Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign – realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign – realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Rate of contacts on campaign.			O
Unanswered, Connected and Abbandoned calls for specific campaign for current day. Leads Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign - realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Overview			
Campaign monitor Leads section displays information about number of Dialling, Connecting and Connected leads for specific campaign - realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download		0		0
Connecting and Connected leads for specific campaign - realtime data. Agents Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Leads			
Campaign monitor Agents section displays information about total number of Agents in queue, as well as number of Logged in and Paused agents for specific campaign realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download		0		0
in queue, as well as number of Logged in and Paused agents for specific campaign - realtime data. List of Agents/Extensions/Callers Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	Agents			
Shows detailed information (Number, Name, Channel ID, Lead, etc.) about each agent and lead with various options (monitor call, transfer call, hangup call). DNC Numbers DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download	in queue, as well as number of Logged in and Paused agents for specific campaign -	0		0
and lead with various options (monitor call, transfer call, hangup call). DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download O	List of Agents/Extensions/Callers			
DNC (Do not Call) Numbers contain a list of numbers not to be dialed by agents. You can upload your list by CSV. These numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible here also. CSV Upload/Download O		0		0
numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible business contact center multi tenant here also. CSV Upload/Download	DNC Numbers			
	numbers can be deleted from the list or added manually. Any DNC number marked by agent trough disposition will be visible	business	contact center	multi tenant
Option to upload/downlaod list of numbers marked as DNC via csv file.	CSV Upload/Download	\bigcirc		\bigcirc
	Option to upload/downlaod list of numbers marked as DNC via csv file.	O		O

Feedback Form			
	business	contact center	multi tenant
Customizable feedback forms Creating custom feedback forms to be used with gloCOM Agents in outbound (dialer) calls.	0		O
Agents			
	business	contact center	multi tenant
Agent Types: Dynamic Agents This type of agents can login with access code *202. The dynamic agent line is always opened, and he is listening Music on Hold when not serving customer calls.	0		O
Agent Types: Callback Agents This type of agent can login by dialing *203 access code. Callback agents phone will ring once they have call waiting to be served.	0		0
Agent Types: Group of Agents To simplify queue and campaign members management administrator can create groups of agents to easily add and remove multiple queue or campaign members. NOTE: Agent Groups act as a template that allows you to move entire group of agents into the queue or campaign and if you add new group members into the group, they will be automatically added to the queues or campaigns you already added this group into prior to that moment.			
Agent wrap-up time Wrap-up time is small time period in which agents will not receive next call after they hang up a call. For example, if agent finish the call, you can assign wrap-up time of 5000 ms (5 sconds) to allow agent to recover before new call is forwarded to that agent.	0		0

Login with PIN if set, agents must provide personal PIN number in order to log in and start taking calls.	0	0
Pause Reason Codes		
When Agent needs to stop receiving calls, but does not want to log out, they are able to use pause and stop receiving calls until they use un-pause option. Under these conditions they will still be reported as logged in but on pause. Agents can provide a pause reason code to indicate the reason they are currently paused. This reason code is logged in with their pause event.	0	
Auto Log off		
Time in seconds that the agent's extension should ring before declaring him unavailable and logging him off.	0	0
Auto Pause	0	
Automatically put agent on pause if she did not answered a call.		
Bind to extension		
Whether the system will bind the agent in question to the extension specified in the Extension field.	0	0
Direct IN		
Agent calls received directly are tracked and logged. This is when agent is dialed directly using agent number and not extension. Those calls are reported as part of agents statistics.	0	0
Direct OUT		
Agent calls made by direct dialing out are tracked and logged. Those calls are reported as part of agents statistics.	0	0
Project Codes		
Agent can now make direct out call, and associate it with Project that is defined on server. Each Project can have defined different Caller Id, so when agent dials with that project, it will use caller id predefined.	0	0

0	O
0	0
O	O
O	O
O	O
O	O
O	O
	0

CC Statistics			
Statistics data will provide necessary tools that will help you to improve your contact center workflow and efficiency, detect bottlenecks and act in order to eliminate them.	business	contact center	multi tenant
Pre-defined Date Ranges: Today			
PBXware statistics allows you to use predefined data statistics filter to display information for current day.	0		0
Pre-defined Date Ranges: Yesterday			
PBXware statistics allows you to use predefined data statistics filter to display information for yesterday.	0		0
Pre-defined Date Ranges: This Week			
PBXware statistics allows you to use predefined data statistics filter to display information for last seven days.	0		0
Pre-defined Date Ranges: This Month			
PBXware statistics allows you to use predefined data statistics filter to display information for current month.	0		0
Pre-defined Date Ranges: Last Month			
PBXware statistics allows you to use predefined data statistics filter to display information for last month.	0		0
Pre-defined Date Ranges: This Year			
PBXware statistics allows you to use predefined data statistics filter to display information for last year.	0		0
Pre-defined Date Ranges: Custom Date range			
PBXware statistics allows you to use predefined data statistics filter to display information for custom date range.	0		0

Other filters: Call Duration		
Using Call Duration filter will allow you to get additional information based on call length.	0	O
Other filters: Hold Duration		
Using Hold Duration filter will allow you to get additional information based on how long caller waited prior connecting.	0	0
Other filters: Time format		
You can change format of value for all time related fields. Possible options are: dd-hh-mm-ss normal time format e.g 01d 02h 03m 04s Days time format in days e.g 1.25d Hours time format in hours e.g 1.25h Minutes time format in minutes e.g 1.25m Seconds time format in seconds e.g 1.25s		
Report actions: PDF Download		
This option allows you to download your reports in PDF format.	O	O
Report actions: CSV Download	0	
This option allows you to download your reports in CSV format.		O
Report actions: Email		
This option allows you to send your reports via E-mail. Report will be delivered in PDF format.	0	0
Report actions: Print	0	
This option allows you to print your reports from HTML page.	O	O
Report actions: Graph	0	\bigcirc
This option allows you to display graphs for your report.		
Report actions: More	0	\bigcirc
This option allows to split you report into shorter date ranges.	J	

Agent statistics			
	business	contact center	multi tenant
Other filters: Agents			
You can filter your reports per specific agents, allowing you to get even more precise information in your reports.	0		0
Agent Reports: Agent availability			
Shows detailed information about agents. It provides a lot of information in a single report to give a quick overview of agent availability to the customer. The main feature here is agent idle time. This report focuses on all calls of agents, sessions, pauses and provides you with accurate information about agent idle time.	0		0
Agent Reports: Agent calls per direction			
Shows a number of calls per direction. For each agent, the data is grouped per agent and then additionally grouped per direction (direct in, direct out, inbound, outbound).	0		0
Agent Reports: Agent direct in calls			
Shows agents direct in calls. The main feature here is calls > 1m. Those calls should be looked like as effective calls. This value is configurable.	0		0
Agent Reports: Agent direct out calls			
Shows detailed information about agents direct out calls. The main feature here are calls > 1m. Those calls should look like as effective calls. This value is configurable.	0		0
Agent Reports: Agent direct out calls per project			
Shows detailed information about agents direct out calls that were made with project codes. The data is grouped per agent, and for each agent the data is grouped per project code. Eg. If one agent made direct out calls with three different project codes, that will be also shown in statistics.	0		0

0	O
0	O
0	O
0	O
0	O
0	0
0	O
0	0

Dialer Statistics			
	business	contact center	multi tenant
Other filters: Campaigns			
You can filter your reports per specific campaigns, allowing you to get even more precise information in your reports.	0		0
Other filters: Members			
You can filter your reports per specific campaign members, allowing you to get even more precise information in your reports.	0		0
Other filters: Lead			
You can filter your reports per specific lead number, allowing you to get even more precise information in your reports.	0		0
Agent Reports: Agent calls	0		
Shows a detailed report about agent outbound calls. Data is grouped per agent.			O
Campaign Reports: Campaign all calls			
Shows detailed information about agent sessions, pauses, talk time and occupancy. The data is grouped per agent. Provides a lot of information in a single report to give the customer a quick overview of agent occupancy.	0		0
Campaign Reports: Campaign calls per disposition			
Shows summary information about campaign all calls which include talk time, hold time and ring time. Data is grouped per campaign.	0		0
Summary Reports: Abandoned calls rate			
Shows the number and percentage of abandoned calls.	O		O
Summary Reports: All answered calls			
Shows summary information about all answered outbound calls. Includes all answered calls dispositions where we can see how did call finished (agent hangups, caller hangups, transferred).	0		0

Summary Reports: All calls Shows summary information about all outbound calls. Includes all calls dispositions which include the total number of calls, number of answered and unanswered calls.	0		0
Summary Reports: All unanswered calls Shows summary information about all unanswered outbound calls. Includes all unanswered calls dispositions where we can see what was the reason for not answering (abandoned, machine, busy, noanswer, cancel).	0		0
Queue Statistics			
	business	contact center	multi tenant
Other filters: Queues You can filter your reports per specific queues, allowing you to get even more precise information in your reports.	0		0
Other filters: Members You can filter your reports per specific queue members, allowing you to get even more precise information in your reports.	0		0
Other filters: Caller You can filter your reports per specific caller number, allowing you to get even more precise information in your reports.	0		0
Other filters: DID You can filter your reports per specific DID number, allowing you to get even more precise information in your reports.	0		0
Agent Reports: Agent dumped calls Shows how many calls agent had dumped. Note that for one call, an agent can dump several times. Total is the number of calls agent had including calls that are dumped. This type of calls happen when agent hang up on the caller while the queue announcement (agent announce) was being played.	0		

Agent Reports: Agent inbound calls		
Shows information about agent inbound calls. Data is grouped per agent.	O	O
Agent Reports: Agent inbound calls per queues		
Shows detailed information about agent inbound calls. For each agent, data is grouped by queue. Users can see here how calls are distributed per agent per each queue.	0	0
Agent Reports: Agent missed calls		
Shows agent missed calls, average of missed calls and total ring time. Important thing here is that we can have more than one missed call for one agent call in queue.	0	0
Queue Reports: Entry positions		
Shows average, min and max entry positions of the calls in the queue. Data is grouped per queue. This is a very important report because from this report we can find out how much load was in queues.	0	O
Queue Reports: Queue answered calls		
Shows more detailed information about queues answered calls. Data is grouped per queue. Includes answered calls dispositions where we can see how did call finished (agent hangups, caller hangups, transferred).	0	0
Queue Reports: Queue callback calls		
Shows information about queues callback calls. Data is grouped per queue. Includes callback calls dispositions which contain the total number of callback calls, number of answered and unanswered calls.	0	0
Queue Reports: Queue calls		
Shows summary information about all queue calls. Data is grouped per queue. Includes Queue Calls Dispositions which contains the total number of calls, answered and unanswered calls.	0	O
Queue Reports: Queue calls per agents		
Shows detailed information about queue calls per agent. Data is grouped per queue. For each queue, data is additionally grouped by an agent. You can see here how calls are distributed per queue per agent.	0	0

Queue Reports: Queue unanswered calls		
Shows more detailed reports about queues unanswered calls. Data is grouped per queue. Includes unanswered calls dispositions where we can see what was the reason for not answering (abandon, exit with key, timed out).	0	0
Queue Reports: Repeated callers		
This report shows statistics of a caller who has called the queue at least two times.	0	O
Summary Reports: All answered calls		
Shows summary information about all answered inbound calls. Includes all answered calls dispositions where we can see how did call finished (agent hangups, caller hangups, transferred).	0	0
Summary Reports: All calls		
Shows summary information about all inbound calls. Includes all call dispositions (Total, Answered, Unanswered).	0	0
Summary Reports: All unanswered calls		
Shows summary information about all unanswered inbound calls. Includes unanswered calls dispositions where we can see what was the reason for not answering (Abandon, Exit With Key, Timeout).	0	0
Summary Reports: Distributions for all calls per day		
Shows all calls per each day. List of days depends on the time range filter.	0	O
Summary Reports: Distributions for all calls per day of month		
Shows you all calls for every 1st, 2nd day of month.	0	O
Summary Reports: Distributions for all calls per day of week		
Shows how the calls were distributed per day of the week.	O	O
Summary Reports: Distributions for all calls per hour	0	
Shows how the calls were distributed per hour.	O	

Summary Reports: Service level agreement			
Service level agreement is calculated per each time range(10, 20, 30, 40,50, 60, 70, 80, 90, 100, 110, 120) as: Service level = Answered calls inside time / Total answered calls * 100	0		0
Summary Reports: Service level agreement inclusive			
Service level agreement inclusive is calculated per each time range(10, 20, 30, 40,50, 60, 70, 80, 90, 100, 110, 120) as: Service level agreement inclusive = 100 - Answered calls inside time / Total all calls * 100	0		O
Voicemail			
	business	contact center	multi tenant
Authentication with PIN			
All users need to provide PIN in order to authenticate when accessing voicemail.			
Voicemail to E-mail (Optional Attachment)			
It is possible to enable all voicemail notifications to be sent to e-mail address assigned to the extension. It is possible to select whether voicemail message should be included in the attachment.			
Voicemail to E-mail (mp3 or wav)			
User can choose whether voicemails will be emailed in wav or mp3 format.			
Custom greeting messages depending on status (Busy, Unavailable)			
Users are able to record their personalized voice messages for "busy" and "unavailable" status, which will be played to callers depending on the current status of their extension.			
Voicemail operator support			
If enabled, callers are allowed to reach operators extension by pressing 0 once their call is forwarded to voicemail.			

Timezone support		
Setting up matching time zone in extensions voicemail settings will make sure voicemail messages are played to users with correct time information.		
Sounds per language		
If sound files in language other than english are uploaded to PBXware alongside default english language prompts, it is possible to set voicemail prompts to be played in preferred language.		
Limit voicemail length		
This option will allow administrator to define maximum lenght of voicemail messages per mailbox, allowing you to limit space usage on servers with large number of users.		
Limit voicemail count		
This option will allow administrator to define maximum number of voicemail messages per mailbox, allowing you to limit space usage on servers with large number of users.		
Voicemail Groups		
Voicemail groups allow you to group multiple voicemail inboxes to a group, informing all users once voice message is left to their group.		
Message Waiting Indicator (MWI)		
MWI option will inform user that they have voicemail message waiting in their mailbox by activating new voicemail message indicator on their phone or gloCOM desktop client.		
Custom greeting for a voicemail group		
We have introduced an administrative option to upload a custom greeting for a voice-mail group. Sound-files can be uploaded via the Sounds section as previously. Sound-files must begin with vm-greeting-*.		
Voicemail CSV upload		
Voicemail upload and Template download available on the Voicemail page. The template is: mailbox, name, pin, e-mail.		

Speech to text ability to specify multiple languages			
This feature is located under: Settings > Voicemail > Show Advanced Options > Transcription. Speech to text ability to specify more than one language for transcription is available. Multiple languages are available only via the Google Speech service.			
Voicemail transcription on the tenant and extension level			
Under the Transcription options for the tenant the "Enable Transcription by Default" has been implemented. This option will determine if the transcription is enabled on all extensions for the tenant by default.	0	0	
Control of voicemail messages from Admin GUI			
An administrator can view all voicemails from the selected voicemail box on the system. To view the voicemails go to: Home > Voicemail > Messages.			
Custom voicemail login and access			
When creating a custom voicemail via Voicemail > Mailboxes > Add Voicemail, a "Password" field is added. This password together with the e-mail is used for the mailbox login. When logged in with this e-mail and password user will only see the Voicemail Page.			
Carbon Copy E-mails			
On the Extensions page under the Voicemail section a field called "Carbon Copy E-mails" is available. "Carbon Copy E-mails" is used to add multiple recipients for e-mails, as BCC. Users can add multiple extensions in this field by typing them out and pressing Enter or the "Add xxxx" option displayed while typing.			
Voicemail lockout			
If a user enters wrong pin for voicemail 3 times in a row, they will be locked out of the voicemail and the administrator will receive an email notification. These 3 failed attempts can be accross multiple calls.			

Monitoring			
Monitoring section allows PBXware administrator to monitor status of main system extensions, trunks, conferences, queues and live channel in real time.	business	contact center	multi tenant
System Extensions			
Extensions panel in Monitoring section will give you an overview of current status of extensions, what user agents (device) are registered to extensions, whether extensions are online or offline, and which extensions are on the call.			
Trunks			
Trunks monitoring panel will display trunks current status (online/offline) and IP address of remote system trunk is registering to.			
Show transport type on monitor page			
Implemented a monitor section for Extensions to check which transport was used aside from TLS that was already implemented (UDP, TCP, WS, WSS).			
Conferences			
Conferences monitoring panel will display a list of available conferences, total activity time in the conference as well as list of active conference members.			0
Queues			
Queues monitoring panel will display information on Agent status (Unavailable, Idle, On call), statistics on queue calls etc.			0
Queue Panel			
Queues panel offers same information as Queues monitoring section, except information in it are adapted for displaying on large screens.			0
Live Channels			
Live channels monitoring panel will display information on active channels and it will allow administrator to monitor, transfer and hangup calls, as well as to see details on selected live channel.			

Filter by IP address			
Added an option to filter data by IP addresses.			
System Extensions and Trunks Warning S	Systen	n	
	business	contact center	multi tenant
Monitoring of SIP and IAX2 system extensions			
Monitoring system can be set to monitor status of SIP and IAX2 peers and if status is changed tit will trigger offline warning notification.			0
Monitoring of Trunks via Outbound Test Number			
In addition to monitoring trunk status it is possible to assign Test number to each trunk. This number will be dialed in predefined interval and if number is unreachable, warning notification will be triggered.			0
E-mail notifications			
If PBXware warning system is enabled notification will be sent to assigned email addresses whenever SIP or IAX2 peer goes offline or Test number on trunk is unreachable.			0
CDR Reports			
	business	contact center	multi tenant
Linked ID for CDR's			
Filtering CDRs by linked ID will display all CDRs that are "linked" to the selected one.			
Control access to recordings			
This feature provides control of who can access and manage call recordings, as well as the recording access history. This will ensure listening, downloading and deleting recordings is available only to authorized users.			
CDR Search and Filters			
The results will display as a call flow with the selected CDR included.			

Listen and Download Call Recordings		
Listen call recordings for specific call by locating specific CDR and downloading attached sound file.		
Call Recordings - Listen recordings in-browser		
PBXware 5 interface now have integrated call recordings player, allowing users to listen PBXware call recordings directly from their browser and navigate through the recording with a simple click of a mouse. This prevents the issue users might experienced with earlier versions, as they had to find a media player that supports format in which recordings were being downloaded.		
Delete Call Recordings		
PBXware allows you to delete call recordings from Reports page.		
Make calls		
You are able to initiate calls from CDR page by selecting one record, picking up one of call parties and entering extension number you wish to use to make the call. Selected extension will ring and once you answer, call to destination chosen in CDR page will be initiated.		
Print recordings		
Print recordings option allow you to click Print icon in order to print out CDR records that are displayed on current page.		
E-mail recordings		
E-mail recordings option allow you to send specific call recording by clicking E-mail icon and entering e-mail address you would like to send CDR records to.		
Information about calls (CLIRs)		
CDR page offers additional call information for easier debugging. To see detailed information about call, click Advanced icon, select checkbox for CDR in question and click CLIR icon to open popup window with full call report.		

CLIR for Exceed Channels		
When the channels limit defined in the license is exceeded the CLIR will show the exact numbers (current > max). The notification email body will contain the same information.		
Origin IP address in CLIR		
Show an IP from which the call was initiated in CLIR.		
CSV Download		
Click this option in order to download .CSV file which will include CDR records based on your search.		
CSV Download with header in CSV file		
Added column names when downloading CSV files.		
Option to disable IP address in CLIR		
Added the option to hide an IP address from CLIR.		
Information about calls (CLIRs)		
CDR page offers additional call information for easier debugging. To see detailed information about call, click Advanced icon, select checkbox for CDR in question and click CLIR icon to open popup window with full call report.		
SMS		
The SMS section on the Reports section displays all the necessary information about SMS messages on the system. For the Multi-Tenant Edition 6.3, it is possible to have access both on the Master and Slave Tenant level. The SMS reports provide information regarding specific Tenants, From/To numbers, Extension numbers, Date/Time together with the 'Direction' field (Inbound/Outbound). Moreover, each entry contains the 'Status' field for various cases, such as 'Received', 'Sent', 'Failed', and 'Pending'. If the message status is marked as 'Failed', there is the 'Error Message' field that specifically explains why certain messages failed.		
Retention policy		
PBXware's retention policy for call recording files now go up to 7 years now.		

Searching CDR by entering 'anonymous'			
This option enables to search reports by entering 'anonymous' in From field, to query the reports for Anonymous (inbound) calls.			
CDR Statistics			
CDR statistics provides all the information related to calls made on your PBXware.	business	contact center	multi tenan
Daily statistics			
Daily statistics displays total number of calls per day for selected date range.			
Compare data by day / month			
Compare section allow you to compare statistic per day/month range by selecting Date range filter.			
Calls duration per month			
Compare section allow you to check call duration per month by selecting month range filter.			
Statistics per Extension			
Extension section allows you to check call statistics per extension.			
Concurrent Calls Report			
Ability to list concurrent calls statistic per tenant / trunk.			
Incoming calls per DID			
DID statistics filter calls per DID.			
File System controls			
All PBXware logs, sound recordings, CLI and CLIR files are stored on the local file system. Some of these files can grow to a size which will not leave any space on the system. This section provides management of how and when these files should be otated or deleted in order to prevent such a scenario.	business	contact center	multi tenan
Set time for deletion of file sharing files			
PBXware admin sets time after files stored from file sharing will be deleted. Default value is 2 weeks.			

Log rotation		
To prevent log files growing too large and consuming all the data on your PBXware's hard drive, data from the main log files is moved to another file after certain period of time.		
Control of log rotation		
Select how often you would like PBXware log files to rotate. (default 2 weeks)		
Other Log files		
Select how often you would like other log files to rotate. (default 2 weeks)		
Files removal control: PBXware CLIR files		
Select for how long would you like to preserve PBXware CLIR files. (default 2 weeks)		
Files removal control: PBXware CLIR files		
Select for how long would you like to preserve PBXware CLIR files. (default 2 weeks)		
Files removal control: Asterisk backup files		
Select for how long would you like to preserve Asterisk backup files. (default 2 weeks)		
Files removal control: Control of Voicemail removal		
Select for how long would you like to preserve Voicemal messages. (default 2 weeks)		
Files removal control: Control of Call Recordings removal		
Select for how long would you like to preserve PBXware Call Recordings files. (default 2 weeks)		
Files removal control: Control of FAX files removal		
Select for how long would you like to preserve received FAX files. (default Never)		
Files removal control: System optimization		
System reload and memory usage on large system optimized.		
Files removal control: System files upgraded		
System upgraded to PHP 7, Rebuilds of binaries.		

Logs			
	business	contact center	multi tenant
CLI messages			
In case your system is experiencing some call issues you can inspect CLI messages log in order to get better understanding of the problem.			
SMTP log			
SMTP log section will provide you useful information on eventual issues with e-mail notifications and messages.			
Sounds and Music on Hold			
	business	contact center	multi tenant
Sounds download / upload and direct conversion of sound files			
There is a progress upload bar and .wav and .mp3 files will be auto converted to other native formats. Other file formats will just be uploaded without automatic conversion.			
Music on Hold customisation			
In order to allow you to customize your system to your preference, Music on Hold classes can be easily assigned to queues, IVRs and even extensions.			
Music on Hold options: Files only, grouped per class			
For easier management sound files are grouped in MoH classes which can contain one or more sound files.			
Music on Hold options: MP3 streaming			
MoH MP3 streaming is set up by simply entering link to a streaming MP3 sound file.			
Music on Hold options: Random playback			
To avoid playing same sound files to callers at all times it is possible to add multiple sound files to single MoH class and enable random playback option. PBXware will shuffle the order in which files are played to avoid monotonous playbacks.			

Routing			
	business	contact center	multi tenant
E.164 routing			
E.164 routing mode is using destination routes based on E.164 numbering rules. E.164 defines a general format for international telephone numbers. Plan-conforming numbers are limited to a maximum of 15 digits, excluding the international call prefix.			
Simple Dial plan Routing			
Simple routing mode allows you to manually create preferred destination routes based on number of digits dialed.			
Disabled routes			
Disabled routes section allows you to enter specific destination routes in order to prevent callers from dialing the numbers that are part of those specific routes.			
Special Routes			
Special Routes feature allows PBXware administrator to add special services numbers that will be distinguished from extensions numbers (even if they have same number of digits) and dialed through specified trunk, simillar to how Emergency Services numbers are dialed through Emergency Trunk.			
LCR			
LCR (Least Cost Routing) section allows fine tuning of the system's trunks usage accordingly to the price and quality.	business	contact center	multi tenant
Setup routing up to three trunks per Destination Group			
LCR allows you to setup up to three trunks to be used according to cheapest price for each available route to lower the costs of calls for you and your customers.			
LCR per system extension			
Mini LCR on extension enables you to override system LCR and allow extension to make calls through different trunks.			

Billing & Service Plans			
	business	contact center	multi tenant
Billing rates, Minimum charge, Connection charge and Billing type per Destination Group			
Billing rates can be set per Destination group but to allow better billing customization PBXware also allows setup of Minimum charge and Connection charge per destination group.	0		
Time-Based Dialling			
Time based dialing allow administrator to set up different billing prices for specific time of the day.	0		
Minimum charge			
You are able to set up Minimum charge amount that will be applied to each call regardless of call duration.	0		
Connection charge	\bigcirc		
Charge applied to any call that leaves the system, regardless if call was answerd or not.	O		
Inclusive minutes			
Adding number of Inclusive minutes to Service Plan will enable callers to spend that time on calls to routes that have Inclusive minutes enabled, free of charge.	0		
Billing increments			
Assign specific billing increment to your Service Plan or route to fine tune billing.	O		
Option to limit service plan for tenants in "Tenant packages"			
An administrator user will now be able to select which service plans are allowed for each tenant. This will allow the restriction of tenant users to only the plans allowed by the administrator.	0	0	

Enhanced services template			
When creating service plan default enhanced services can be selected, which will be available in OSC for end user.	0		
Change word 'Billing' with 'Call Rating'			
Systemwide changed word 'Billing' with 'Call Rating'.			
Call rating cost in OSC and CDR			
Options button "Show Call Rating Cost in OSC". When used on the extension it affects OSC and when used on a group it will affect all users that are in that group. If this option is set to "No" or is not checked then when looking at CDRs the Rating Cost column will not be shown.			
LCR page visible on Master Tenant			
On Tenants it can set to use System Default LCR (the one on Master Tenant) or not. If Use System Default LCR is set to On then the configuration on that tenant will be ignored and the configuration on master tenant will be used. If it is set to Off then the configuration from that tenant will be used.			
CRM Integration			
	business	contact center	multi tenant
SugarCRM			
PBXware supports SugarCRM 6.5 and later.			
SalesForce			
DDVWara augmenta Calca Faraa CDM			
PBXware supports SalesForce CRM.			
ZenDesk			
ZenDesk			
ZenDesk PBXware supports ZenDesk CRM.			

Microsoft Dynamics CRM		
PBXware supports Microsoft Dynamics 2015 CRM.		
Bullhorn		
PBXware supports Bullhorn CRM.		
Vtiger		
Support for Vtiger CRM.		
The SuiteCRM		
Support for The SuiteCRM.		
Pipedrive CRM		
Support for Pipedrive CRM.		
CRM routing		
CRM Routing allows routing to a specific queue or IVR, or playing sound files based on information fetched from CRM. So, when the call comes in AGI, we will first contact CRM and then based on the result will make a specific action. Into PBX ware Home tab we added CRM menu with Integration and Routing submenu. On Routing submenu one can set up rules based on which call is to be routed. On DID and IVR we added new destinations where one can select the rule which will be evaluated for particular DID/IVR.		
SugarCRM		
Added support for API v10+.		
Hubspot		
Support for Hubspot CRM.		

E-mails			
	business	contact center	multi tenant
E-mail notifications control			
E-mail notifications control allows you to control which e-mail notifications will be sent to administrator.			
E-mail Templates			
E-mail templates alows you to edit the content of each E-mail notification message that is sent to users and administrators. Number of available variables enables you to provide information tailored to specific user.			
E-mail Template for Call rating			
New email template for Call Rating added to email templates.			
Extension email templates per tenant			
Extension email templates per tenant will allow creating customized extension email templates for every tenant.	0	0	
Proxy value for voicemail templates			
Variable %PROXY% is available for Email Templates, references the value of gloCOM SIP Proxy in the tenant / server settings.			
%TENANT_CODE% variable to 'Voicemail Blocked Email Template'			
Added the %TENANT_CODE% variable to 'Voicemail Blocked Email Template'.			
GUI notifications			
GUI notifications warn users about license expiry date, new updates and status of emergency trunks setup in order to prevent potential system issues.	business	contact center	multi tenant
License notifications			
PBXware GUI displays notifications on upcoming license expiry. Administrator will be informed both in web interface and by e-mail (on servers that have SMTP server configured).			

Update notifications			
Update notifications will be pushed to PBXware GUI, notifying Administrators about new PBXware releases and informing them of new features/bug fixes.			
Emergency Trunks Notification			
On systems that do not have Emergency trunks assigned, warning will be displayed in notification bar, informing administrators of potential issue.			
DTMF Access Codes			
DTMF access codes allow PBXware users to easily access and manage number of PBXware features.	business	contact center	multi tenant
Access Voicemail			
Voicemail box is accessed by dialing *123 on phone connected to users extension. In addition, to access voicemail box from other extensions on PBXware, users can dial *124 and then authorize with personal extension number and PIN.			
Voicemail Transfer			
To transfer call to extensions voicemail dial # *125 while on active call, followed by the number of extension you would like to transfer call to.	0	0	0
Agents Login / Logout / Pause / Not Ready			
PBXware allow users to enter range of access codes to log in/out agents, pause them or put them in not ready state.			0
Instant Call Recordings			
When enabled in enhanced services users can start call recording at any point in live call by dialing *159.			
Pause/Unpause Call Recording			
To pause call recording, while on active call, users can dial *9. This is useful for situations where customer is providing personal data like credit card number. Once done, in order to continue call recording users can dial *91.	0	0	0

Start Monitoring a Call			
Users with Call Monitoring enabled, in extensions enhanced services, are able to listen active conversations by dialing *199 followed by the number of extension they would want to monitor, while that extension is on the call.	0	0	0
Paging			
Users can dial *399 to relay voice message to predefined set of extensions. To page single extension users have to dial *400 followed by number of extension they would like to page. Some phones require additional setup in order for speakerphone to activate automatically when device is paged.			
Paging a Group Through Speakerphone			
Dial *600 followed by the number of paging group you would like to page in order to broadcast the message over speakerphone of extensions that are members of this paging group.	0	0	O
Speed Dial			
Dial *130 followed by short code assigned to number you frequently dial in order to initiate speed dial to specified number.			
Select Other Networks			
Other network feature allow you to force calls to go through specific trunk by entering assigned number that can be 1-3 digit in length. If Other Networks option is set up to be used with numbers longer than 1-digit, access code *188 must be entered before assigned number and this is followed by the number caller wish to dial. For example, if you assigned 231 as an Other Network number for Trunk D, to force call to go out through that trunk you must dial *188 231 followed by number you wish to call.			
Listen to CDR Recordings			
Access code *170 is used when user want to listen last 9 Call Recordings from CDRs page. For example User can dial *170 from their phone followed by a number between 1 and 9, where 1 is most recent recorded conversation.			

Toggle Call Forwarding			
Dial *71 on your extension to enable call forwarding rules predefined in extensions enhanced services. To disable call forwarding dial *72.			
BLF toggle for Call Forwarding			
Implemented the BLF toggle for Call Forwarding.			
Toggle Group Hunt			
Dial *510 on your extension to enable Group Hunt rules predefined in extensions enhanced services. To disable Group Hunt rules dial *511.			
Block Your Caller ID			
You are able to block your Caller ID by entering *67. Blocking will be in effect until you use *68 to unblock caller ID. If you would like to temporary block your caller ID, dial *81 to block it for next call only.			
Call With CallerID			
If extension have a list of Allowed CallerIDs set, users can use access code *65 in order to use one of the available caller IDs to make temporary change of caller ID. Although this feature is meant to be used with gloCOM we have still make it available for use over deskphone.	0	0	0
Toggle Follow Me Rules			
Dial*520 on your extension to enable Follow Me rules predefined in extensions enhanced services. To disable Follow Me rules dial *521.			
Call Parking			
If you would like to park call to available parking slots dial *700 while on call. System will play notifications to what parking slot number your call was parked. Default parking slot range spans starts at 701 and ends at 720. This can be changed from Settings \rightarrow Access Codes page.			

Direct call parking		
This feature allows you to directly park calls on a specific parking lot (701-720). e.g. to park a call in a parking lot 710, dial *710. If the specified parking lot is busy, the system will dial the next available parking lot. In order to pick up a call, dial the desired parking lot, or if you have set the BLF on your phone, you can simply press the corresponding BLF button.		
Enhanced Call Parking		
While on active call you can dial '#800'. The call will be parked and Announce Extension will ring for set number of seconds. After that period call will be directed to Timeout Extension. Timeout, Announce Extension and Timeout extension must be set under Settings \rightarrow Servers/Tenants \rightarrow Master Tenant/TenantName \rightarrow Enhanced Call Parking (section).		
Test Music on Hold		
To perform system test for default music on hold class, dial *388 from your extension. If everything is ok you should be able to hear your MoH class playing without any issues.		
Echo Audio Read		
Users can dial '*398' and talk into the phone. Everything they say will be played back to them to allow them to check server response time.		
Record greetings		
Dial *301 on your extension to record greeting messages from your phone. Greeting messages recorded this way can be found in Sound files section under letter G and will be named greeting-DATE-TIME. Rename them to required format to use them with other PBXware elements.		
Toggle Operation Times		
Use *401 on your extension to open your systems operation times or *402 to close it. Extension must have Operation Time option enabled in extensions Enhanced Services.		

Reset Operation Times			
Users can dial *403 to reset Operation Time rules once they had to open them in order to allow calls to come in after closed time. In order to use this feature, Operation times must be closed first using *402.	0	0	0
Hot Desking			
Users can dial *555 in order to log in or log out of their hot desking extension.			
Customizable Access codes for call pickup			
1.UnderSettings>Accesscodes,addedcodesforcallpickupusing*8and*88+EXT_NUM 2. Under Extension > Enhanced Services added codes for call pickup using *8 and *88+EXT_NUM next to the Call Pickup			
Toggle Do Not Disturb feature			
Implemented an Access Code as a toggle for the ""Do Not Disturb"" feature, the default value is *77. This Access Code can be used as a BLF in the BLF/Directory list by adding *77XXX, where XXX is the extension number. When used as a BLF, the button will also switch colors when DND is enabled/disabled.			
Voicemail transfer between tenants			
During an active conversation users can dial '*125 + \$TENANT + \$EXTENSION' to transfer the calling party to a system \$EXTENSION number voice box.			
Greeting access code for specific destination type (IVR, Ring Group etc)			
Change Greeting: defaults to *303 and takes a queue/IVR or ring group as destination. When dialed the user is prompted to record a new greeting. Once accepted the greeting is set as the destinations new greeting. Change Greeting: defaults to *304 and takes a queue/IVR or ring group as destination.			
Toggle Operation Times			
Dialing *405 will toggle *402 / *403 access codes.			

Transfer call to voicemail on different tenant			
Redirect an ongoing call to a voicemail on a different tenant by dialing *125 + tenant extension.			
FAX			
	business	contact center	multi tenant
SIP T.38 support			
PBXware supports T.38 standard for faxing over SIP.			
Sending faxes			
PBXware supports sending of FAXes using gloCOM desktop app.			
Receiving faxes (E-mail)			
Fax to E-mail option on PBXware allow you to receive faxes in digital form and to automatically send them to specified e-mail address. Received FAXes will stay preserved on the server as well. In addition, it is possible to connect FAX machine to ATA device in order to receive FAXes in conventional manner.			
Viewing faxes in TIFF / PDF format			
In FAX section of PBXware GUI you can see a list of FAXes received through Fax to E-mail feature. You can download them in TIFF or PDF format and view them on your computer.			
FAX Cover page customisation			
PBXware allows you to set general FAX settings for FAX cover page which will be applied on every fax that is sent from PBXware. Additional options are available in gloCOM desktop client.			
Sending faxes between PBXware instances (Remote FAX functionality)			
This options allows you to configure PBXware to transfer all incoming faxes to remote system.			

FAX caller ID			
Choose CallerID when sending fax from list of predefined caller IDs. gloCOM users can choose different caller IDs, from predefined list in PBXware GUI, for sending a FAX.			
Email to fax			
This is a service that allows people to send faxes via e-mail.			
An e-mail can have multiple files attached but there is a configurable limit on those files, the default is max. 5 files per e-mail. E-mail To Fax must be enabled on the license.			
Allow Caller ID Option to have both name and number			
This option enables to set both caller id name and caller id number for Email to Fax Caller ID.			
Requeue Timeout			
This option defines the number of seconds after which a failed Fax try will be requeued.			
Choose Trunks to use			
Set the primary, secondary and tertiary trunk for Email to Fax feature. These trunks would then override the trunks set on tenant/server level.			
Email Addresses Whitelist			
Whitelist which email addresses can use Email to Fax feature.			
GUI Global Settings			
PBXware graphical interface allows you to configure and supervise your PBX faster, easier, and much more efficient than any other product on the market.	business	contact center	multi tenant
Global Administrators			
Besides main administrative accounts PBXware GUI allows creation of additional administrator accounts so users do not have to share single account.			
Site / Tenant Administrators			
To give customers management over settings on rented tenants administrator can create lower level administrator accounts with tenant level administrative privileges.			

Option to force 2FA for GUI users			
Added the option to enforce 2-Step Verification for users and administrators.			
Action Logs			
Action Logs feature will provide information on what changes are made, who made them and when, it can also help you detect unauthorized access by storing information of IP addresses from which connection to your PBXware was established.			
Different action log for "Download" and "Listen" actions			
Separated logs for CDR Download and Listen actions. logs are available for CDR Download and Listen actions. These can be found under Admin Settings > Action Logs.			
Action Logs			
Added the CDR ID to show which recording was played and downloaded.			
Admins/users permission to create Tenants			
Granted admins/users permission to create tenants along with other permissions. Full administrator access will not be granted but will be able to create tenants.	0	0	
Date/Time format settings			
PBXware GUI allows you to Set/Change date time format settings according to your location.			
Timezone per Tenant, Timezone per Extension			
Setup a default timezone for a tenant that will apply to all extensions on target tenant. Also added option on extension to change time zone for extension only. This option will enable usage of one multi tenant in different time zones.	0	0	
Language settings (Internationalisation support)			
PBXware GUI is already translated to several languages but in case your language is not available, Bicom Systems will provide you with translation files which will allow you to translate PBXware GUI to your preffered language.			
New language added			
French language translation added for GUI.			

Branding			
Branding allows you to customise PBXware GUI with your company logos and/or colors.			
gloCOM WEB branding for OEM partners			
gloCOM WEB branding for OEM partners.			
Simple Branding for Online Self Care			
This offers a possibility to brand the Online Self Care including the logo change. Location of the feature is: Admin settings > Branding > Online Self Care.			
Sessions			
To prevent unauthorized access to PBX ware web interface we created automatic account suspension feature. By default, accounts will be suspended after 5 unsuccessful login attempts in 1 minute but users can change these values to match their preferences. After account is suspended it will have to be unlocked by administrator.			
CDR extension limit - advanced options			
A drop-down is added on the "Allow CDR extensions field" in user groups which will expand this field's functionality. 1. Including > All CDRs that include the selected extensions can be shown. 2. Between > Only calls BETWEEN the selected extensions can be shown. 3. From > Only calls made FROM the selected extensions can be shown. 4. To > Only calls made TO the selected extensions can be shown.			
Speed Dial settings can be managed per tenant			
The Speed Dial page is available per tenant - Tenant > Settings > Speed Dial. The Speed dial page was available only on Master tenant before.	0	0	
Prevent users from deleting call recordings			
Prevent user from deleting call recordings.			

Branding			
	business	contact center	multi tenant
Simple branding			
Simple branding feature allows users to easily upload custom logo and change interface colors from PBXware GUI by simply clicking the mouse.			
Custom CSS branding			
Advanced users are able to modify CSS files to visually adapt PBXware GUI to their preference.			
Custom Login logo			
Your company logo can be uploaded to replace default Bicom Systems logo displayed on the PBXware login page.			
Product name branding			
Bicom Systems is offering an option to change PBXware name to match our customers preferences. For more information please contact your account manager.			
GUI Tools			
	business	contact center	multi tenant
In-browser Asterisk CLI			
To make it easier for our customers that do not have as much experience working in a terminal environment, PBXware 5 has an integrated Asterisk CLI monitor in its interface. The Asterisk CLI is accessible on main administrative accounts on PBXware and does not require a root password to access it. While this may sound like a potential security issue, we have prevented problems by allowing the execution of monitoring commands only when using the in-browser Asterisk CLI. Apart from permissions being limited, you will be able to use debugging and other monitoring features the same as if you were logged in to the Asterisk CLI from the shell.			

E-mail notifications are a useful tool for PBXware administrators as well as end users. By providing automatic reports on system status and issues or automatically emailing access details when new users are created, administrators will be relieved of the additional workload. At the same time, the end user experience is improved through the use of different e-mail notifications. In 5.0 we made things even better with a SMTP Log that is built-in to the PBXware interface, allowing easy debugging in cases where e-mails are not delivered. To see the issue, simply navigate to Reports → SMTP Log, from the Home tab of PBXware settings.			
Supported Browsers (GUI)			
	business	contact center	multi tenant
Internet Explorer 10+			
PBXware GUI supports Internet Explorer version 10 and later.			
Safari			
PBXware GUI supports Safari web browser.			
Google Chrome			
PBXware GUI supports Google Chrome web browser.			
Firefox			
PBXware GUI supports Firefox web browser.			
HTTP API			
In general terms, API is a set of clearly defined methods of communication between software components, or in our case between PBXware and custom solutions developed for working with PBXware.	business	contact center	multi tenant
Extensions			
You can add, edit, configure and delete or list PBXware extensions through API queries. In addition to these options it is possible to manage extension billing through API.			

Trunks			
API queries can be used to list Trunks available on PBXware.			
Trunks extended API			
Trunks: Add, Edit, Delete, Tenant actions.			
DIDs			
It is possible to add, edit, delete or list PBXware DIDs through API queries.			
DID groups API queries can be used to add, edit, delete or list DID groups on PBXware 5.0 MT.	0	0	
Ring Groups			
It is possible to add, edit, delete or list PBXware Ring groups through API queries.			
IVRs			
It is possible to add, edit, delete or list PBXware IVRs through API queries.			
CDRs			
It is possible to download CDRs and get information on billing ammounts through API requests.			
Routes			
It is possible to list available PBXware Routes using API queries.			
Servers			
On Bussines and Call Center edition you can use API queries to get server configuration details.			0
Enhanced services			
Enhanced Services API update, all enhanced services are exposed in new APIs.			
Tenants			
On MT edition it is possible to add, edit, delete or list PBXware Tenants through API queries.	0	0	

Service Plans			
API queries can be used to list available service plans and list prices for available destination groups.	0		
Print the API doc from within PBXware			
Print the API doc right from PBXware.			
Advanced API keys management			
Advanced API keys management allows: Multiple API keys, Defining allowed actions per key, Which tenant ID can be accessed, Limit API key access per IP address (or address range), Add API key expiry, Add information about last access of API key, browser, IP address.			
Apps license info			
Added the ability to get a count of the application licenses assigned to a Tenant.			
License refresh			
Added the option to refresh a license via API.			
Added location and department info in extensions list			
Added location and department info in extensions list API responce.			
Departments			
Added option to fetch list of departments.			
Dashboard			
Added option to fetch information from Dashboard page.			
Monitor / Extensions			
Added option to fetch information from Monitor \rightarrow Extensions page.			
Monitor / Live Calls			
Added option to fetch information from Monitor \rightarrow Live Calls page.			

Setup Wizard			
	business	contact center	multi tenant
Timezone configuration			
In this part of setup wizard administrator is able to set up or change default time zone on PBXware.			
Administrator password			
PBXware setup wizard will allow you to create/change main administrator username and password.			
Licensing			
Licensing section allows administrator to apply new or reapply updated PBXware license when needed.			
Services control			
From Services control section administrator can stop, start or restart server services like PBX service, PBXware, HTTP service, Database service etc.			
SMTP Configuration			
Configure your PBXware with mail account in order to send out notification e-mails to users and administrators.			
G.729 codec and license installation			
G729 section of PBXware setup wizard allows you to easily apply G.729 codec licenses to your PBXware.			
Updates and Upgrades			
You can easily update or upgrade your PBXware server from Updates section. This feature only allows update between minor versions like 4.1 to 4.1.2 while major versions upgrades, 4.0 to 5.0 for example, can only be performed by trained Bicom Systems staff members.			

Remote Logs		
Remote logs feature allow you to connect your PBXware to remote MySQL database in order to store CDR database on remote server. Please note that if this feature is enabled, in case connection to database server is interupted, you will not be able to access CDR data until connection is reestablished.		
SSL Certificate import		
Setup wizard allows you to create and download your PBXwares private key and CSR files in order to send them to certificate authorities. In addition, once you receive your certificate files you can use this tool to install it on your PBXware.		
SSL Certificate integration with Let's Encrypt		
With Let's Encrypt integration in PBXware 5 our users will not have to worry about when their SSL certificate is about to expire as PBXware and Let's Encrypt service will renew the certificate every 90 days automatically without any need for user interaction.		
Let's Encrypt is a free, automated, and open Certificate Authority used for setting up an HTTPS server and having it automatically obtain a browser-trusted certificate, without any human intervention (https://letsencrypt.org/).		
This means the customer will need to install the certificate only once and it will be automatically renewed once it is about to expire.		
Backup		
Manually initiate PBXware backup or set up a backup to run daily by selecting option in Backup section. It is possible to exclude Recordings, Voicemails, CLIR files and/or Log files in order to preserve space.		
QoS		
If you are experiencing call quality issues because of high network load, you can set tag VoIP packets based on your preferred QoS settings.		
Progress bar in Setup Wizard		
Progress bar in Setup Wizard is added to show info about updates on tables.		

BSSUP			
Integrated BSSUP with PBXware.			
Auto Provisioning			
	business	contact center	multi tenant
HTTP/HTTPS provisioning with Authentication			
PBXware supports HTTP/HTTPS provisioning with Polycom, Yealink, Cisco SPA, Grandstream, Snom, VTech, HTek, Denwa, Gigaset, Fanvil, Panasonic and Obihai devices.			
TFTP provisioning			
PBXware supports TFTP provisioning on all devices.			
TFTP provisioning enable/disable			
TFTP startup can be controled in GUI (Master Server / Master Tenant).			
Exposing variables in Additional config			
Security improvement			
Implemented client certificate validation.			
Supported Devices			
Wide range of supported UADs is advantage PBXware is providing for its users. With suport for all major brands in the industry we also offer support for range of devices not as widely supported on other platforms.	business	contact center	multi tenant
Phones			
Aastra			
Supported Aastra models: 480i, 53i, 55i, 57i, 9112i, 9133i.			
Alcatel			
Supported Alcatel models: IP100, IP150, IP200, IP300, IP600, IP800, IP1020, IP2015.			

Grandstream		
Supported Grandstream models: BT-102, BT-101, GXP-2000, GXP-2124, GXP-2160, GXW-4004, GXP1625, GXP1628, GXP1630, GXP1782, GXP2170, GXV3275, GXP2130, GXP2135, GXP1615, GXP1760W, GXP2140, GRP2612, GRP2613, GRP2614, GRP2615, GRP2616, HT802, HT818, DP752, GXV3350, GXV3370, GXV3380.		
Gigaset		
Supported Gigaset models: Maxwell Basic, Maxwell 2, Maxwell 3, Maxwell 10		
Supported Gigaset DECT model: N720, N510, N870.		
Cisco		
Supported Cisco models: 7940, 7941G, 7942G, 7945G, 7960, 7961G, 7962G, 7965G, 7971G, 7975G, 8851, 7821, 8841, 6851, 8865.		
WARNING: Cisco 79xx devices, other than 7940 and 7960, will not be able to work if PBXware is not in the same LAN.		
Cisco SPA		
Supported Cisco SPA models: SPA 301, SPA 901, SPA 501G, SPA 502G, SPA 504G, SPA 508G, SPA 509G, SPA 525G2.		
Denwa		
Supported Denwa models: DW-210P, DW-310P, DW-610P.		
Fanvil		
Supported Fanvil models: X4, H3, H5, X2P, X3G, X3S, X4G, X5S, X6, X3U, X5U, X6U, V62, V64, V65, V67, X7A.		
Hanlong		
Supported Hanlong models: UC902P, UC903, UC923, UC924 UC926.		
Htek		
Supported Htekmodels: UC802P, UC803P, UC804P, UC806P, UC840P, UC842, UC860P, UC862, UC912P, UC912G, UC924E, UC926E.		

Huawei		
Supported Huawei models: eSpace 7910, eSpace 7950.		
Mitel		
Supported Mitel models: 6867i.		
Panasonic		
Supported Panasonic models: KX-HDV130, KX-UT113, KX-UT123, KX-UT133, KX-UT136, KX-TGP550, KX-UTG300B.		
Linksys		
Supported Linksys models: SPA-941, SPA-942, SPA-962.		
Obihai		
Supported Obihai models: OBi110, OBi202, OBi302, OBi504, OBi508, OBi1022, OBi1032, OBi1062.		
Polycom		
Supported Polycom models: IP301, IP320, IP321, IP330, IP331, IP335, IP450, IP501, IP550, IP560, IP601, IP650, IP670, IP5000, VVX101, VVX 201, VVX 300, VVX310, VVX400, VVX410, VVX500, VVX600, VVX1500, VVX150, VVX250, VVX350, VVX450, VVX411, VVX501, VVX x50 OBi Edition, VVX601.		
Sangoma		
Supported Sangoma models: S500, S505, S700, S705.		
Snom		
Supported Snom models: 320, 360, 190, D315, D345, D375, D713,D715, D745, D785, D785, D735, D717, D120, D335, D385, M900, PA1, M300, M900.		
Vtech		
Supported Vtech models: VCS754 VSP600 VSP715, VSP726, VSP736, VSP725, VSP735, VSP716A, VSP726A and VSP736A, VDP650, ET605, ET617, ET635, ET685		

Yealink Supported Yealink models: T18P, T19P, T20P, T21PE2, T22P, T23G, T26P, T27P, T28P, T29G, T32P, T38P, T41, T41S, T42G, T42S, T46G, T48G, T48S, T49G, T58V, W52P, W56P, CP860, T60P, T65P, CP920, CP960, T40G, T52S, T64S, T56A, W60B, W53H, T53W, T52, T54W, CP020W, W80P, VP50, T57W, T41U, T42U, T43U, T46U, T48U, T			
T53, T54W, CP930W, W80B, VP59, T57W, T41U, T42U, T43U, T46U, T48U. ATAs			
Grandstream			
Supported Grandstream ATA models: HT-286, HT-386, HT-486, HT-488, HT-496, HT-502, HT-503, HT-701, HT-702, HT-704, HT-814.			
Cisco			
Supported Cisco ATA models: SPA112.			
Linksys			
Supported Linksys ATA models: PAP2.			
Obihai			
Supported Obihai ATA models: OBi302, OBi110, OBi202, OBi300, OBi302, OBi504, OBi508.			
Sipura			
Supported Sipura ATA models: SPA-841, SPA-1000, SPA-2000, SPA-3000.			
ReadyNet			
Supported ReadyNet models: AC1200MS, AC1000MS, AC1100MSF, QX300.			
UAD settings on Master tenant			
This extends the ability to set specific settings on the Master tenant for UADs. These settings are inherited when creating tenants.	0	0	
EOL Devices list			
End of life devices will be shown and flagged in UAD list.			

CNAM Integration			
	business	contact center	multi tenant
CNAM Lookup			
When phone calls are made, there are usually two user-facing identifiable pieces of information: a phone number and a Caller ID Name. CNAM can be used to display the calling party's name alongside the phone number, to help users easily identify a caller.			
There are numerous CNAM lookup services which allow you to pay a small fee to lookup the CNAM of a specified caller and PBXware now allows you to integrate with them.			
Support for CNAM providers with text/plain response type Added support for CNAM providers which return plain text instead of json response.			
Archiving			
	business	contact center	multi tenant
Archiving with FTP, Amazon S3 and Dropbox			
PBXware 5.0 includes a remote storage feature that can be used to keep your recordings, voicemails, and FAXes on a remote location. You can choose between three options for remote storage: Amazon S3, FTP server, or Dropbox. You can either keep these files on both your PBXware server and the remote server for backup purposes, or set files to be removed after the upload to preserve space on PBXware.			
Archiving with Bicom Archiving Storage (BAS) and SFTP			
Archiving can be used now with BAS in ServerWARE and with SFTP which provides a secure way to transfer files.			
Rename to Archiving Storage			
Formerly known as "Remote storage" is "Archiving storage".			
Google Drive support			
Customers can use Google Drive for archiving storage.			

Archiving Storage Optimization		
Control of MP3 conversion, upload rate control, upload retries and email notification are exposed in GUI. 1. Added option for control over MP3 conversion in PBXware GUI for archiving storage. This way users can choose either to compress uploaded recordings or leave in native format. 2. "Upload Rate" field is exposed in GUI for users, this way users can manage upload rate to avoid network issues if necessary. 3. "Max Retries" field is exposed in GUI for users to enter maximum number of upload retries for single file in a case of network error. 4. Added E-mail Norifications for failed uploads.		
Archiving Storage, schedule archiving		
A scheduling option introduced to Archiving storage on the master tenant/server. User can select the frequency in which the archiving storage daemon will execute data offload.		
Access recordings from GUI (S3/Google Drive)		
This feature enables customers to listen to the remotely stored recordings from the GUI as well as download them. Recordings are streamed directly to the client and no local files are created on the system during the features use. There is a new option in CDR GUI page which replaces the listen button for a specific CDR which represents the option to listen to the remotely stored record and is indicated by the service the record is stored on. This option is controlled by the licence.		
Bandwidth Control		
To prevent Archiving Storage data upload to make a negative impact to your network performance PBXware enables you to easily restrict maximum upload speed, by entering the number of KB/s which will be used for upload to remote storage servers. Data is by default synced once a week.		
Remove Files		
When enabled, Remove files option will delete the data on PBXware after transfer to remote storage server is successfuly completed.		

Reports page Reports page for Remote Storage is located under Home → System → Storage in your PBXware GUI. Here you will be able to see whether transfer was successfull or failed, along with information on numbers of recordings, voicemail and FAXes that were uploaded to remote storage location.			
Tenants / Servers			
	business	contact center	multi tenant
Not Active tenant status			
When set to not active, extensions can not be reached and the tenant is not available in the dropdown.	0	0	
Suspended tenant status			
When set to suspended, extensions can be dialed, but they can not make calls.		O	
Notification when an emergency service is called			
When 911 is dialed, an automated call goes out to a specified number or extension or ring group, playing an announcement that 911 was dialed from this extension. This can be done in ring all or ring single strategy.			
Emergency Services: Notification E-mail Improvement			
In the previous version, users could enter 'Police', 'Fire', 'Ambulance' emergency numbers and a notification e-mail as a part of configuration for 'Emergency Services'. This is now improved, as users can enter one or multiple e-mail addresses depending on their preferences and needs. The box is also resizable, which makes the usage more convenient.			
%LOCATION% variable in the 'Emergency Call Template'			
Added the %LOCATION% variable to 'Emergency Call Template' on Extensions.			
Set maximum file size for file sharing			
PBXware admin sets maximum size of file that can be sent with file sharing. Value can be set between 25MB and 250MB, default value is 50MB.			

STIR/SHAKEN			
Added the implementation of call signing and verification with STIR/SHAKEN.			
Meetings			
	business	contact center	multi tenant
Meetings list: Scheduled			
This list shows all Meetings that will be held in the future.			
Meetings list: Recent			
This list shows all Meetings that have already been held.			
Meetings list: Date Range			
This list shows all Meetings for the period selected beginning from the Start Date and finishing with the End Date.			
Meeting details: Status			
Shows the Meeting's status.			
Meeting details: Date/Time			
Date and Time showing if the Meeting will take place or it has been held.			
Meeting details: Duration			
Time duration of a Meeting.			
Meeting details: Organizer			
Name of the Meeting's organizer and his/her Extension.			
Meeting details: List of Participants			
Shows Name and Extension of every Meeting's participant.			
Meeting details: List of DIDs			
All DIDs in the Meeting.			

View Base Meeting			
The button 'View base meeting' is visible only if a Meeting is recurrent. By pressing it, further information on Base Meeting becomes accessible.			
View Base Meeting: Meeting details			
Users may click the button 'Meeting details' if they want to return to the "Meeting Details" page as presented on the screenshot.			
Meeting management			
Create, Update and Delete meetings.			
Meeting Settings: Meeting Join links customization			
Meeting join link can be customized, so custom landing pages can be used.			
Option to hide meeting button in gloCOM			
Ignoo connector change that will enable hiding of the Meeting button in gloCOM due to GDPR Compliance.			
Meeting settings			
	business	contact center	multi tenant
Daily digest: Time Zone			
Preferable Time zone.			
Daily digest: Use Custom Settings			
If this option is off, any settings set on the system will be used.			
Daily digest: Week Days			
Specifies days in a week when e-mails will be sent.			
Daily digest: Daily digest time			
Time of receiving daily e-mails.			

Touchless provisioning			
Feature that allows simple and fast phone provisioning. Allows the administrators to register the phones to provider's redirection services. After the phone is registered it needs to be factory reset and it will be provisioned automatically. No changes in the Phone's User Interface are needed.	business	contact center	multi tenant
Support for Yealink Phones			
Acquire an RPS account from the Yealink support and find the API AccessKeyID and AccessKeySecret. Enter those values in the User Interface and Yealink phones are ready for use with the Touchless Provisioning Feature.			
Touchless Provisioning Mode			
Set where touchless provisioning can be configured, only on Master Tenant or Per Tenant.	0	0	
Touchless Provisioning Devices			
A page where it is possible to see all devices that can use the touchless provisioning feature.			
Touchless Provisioning Reports			
All requests and their results to the provider's redirecting services can be seen under Reports > Touchless provisioning.			
Touchless Prvisioning			
Allowed setting HTTPS as the provisioning protocol.			
Central Phone Book			
	business	contact center	multi tenant
Define a Global Phone Book			
PBXware admins can add contacts to a global Phone Book which will be sent to gloCOM and to some phone models. Supported models as Yealink, Polycom and Cisco. To enable phone book for phones you need to enable LDAP option on Servers/Tenants > Edit page.			

business	contact center	multi tenant
business	contact center	multi tenant

DSM reports			
Shows sync reporst.			
DSM summary			
If 'Yes' is selected, users will receive a summary e-mail to the defined e-mail address. By default, the E-mail template includes the Date, number of Added/Edited/Deleted Extensions, and number of failed syncs. In case the number of failed syncs is larger than zero, the e-mail is sent together with an attachment containing the error message explaining why each sync failed.			
DSM summary email template			
Set the e-mail template to be generated for any changes, errors, or failed Extension syncs. The %ATTACHMENT_MESSAGE% variable refers to the .txt file that will be sent together with the e-mail. It contains further information about why the sync failed or problem arose.			
Spacial characters in password field			
Implemented supporting special characters when authenticating users with 'Directory Sync Management'.			
SMS			
	business	contact center	multi tenant
SMS Trunks			
The Trunks section allows users to create SMS Trunks and specify configuration details. The first page displays a list of all Trunks that have been created on the system. The 'Provider' field displays the provider that was chosen for that specific Trunk, so that users have all the information accessible at first glance. From here, users can add new Trunks and configure them accordingly. Additionally, they may edit and/or delete the existing ones.			

SMS Trunks & Tenants		
On the Multi-Tenant Edition 6.3, the Trunks & Tenants section permits users to assign specific SMS Trunks to Tenants that have been previously created. When users navigate to this page, the list of all Tenants on the system together with their codes will be displayed. If there are any SMS Trunks assigned to Tenants, they will be displayed for easier tracking and organization. From here, users can only edit the configuration for SMS Trunks and Tenants.		
SMS Numbers		
The Numbers section allows users to add numbers to the system and assign them to specific Extensions. From this section, it is possible to manage the configuration of numbers by editing or deleting it.		
Bandwidth as SMS provider		
New SMS provider has been added, with support for SMS, MMS and Bulk Messaging.		
Twilio		
Added Twilio as an SMS provider.		
MMS		
Apart from SMS, users can now send and receive MMS (Multimedia Messaging Service) that includes multimedia content. Being able to send visual content is an effective way of keeping others informed with time-sensitive information. In the Reports section, users can see which type of message is sent or received.		
Bulk Messaging		
The Bulk Messages section allows users to send bulk SMS messages. By using this feature, users can send important information to a larger number of people. Apart from adding Bulk SMS messages through the GUI, users can easily upload their data by using CSV files or filter their Bulk SMS messages by status. They can start new Bulk messages or stop the active ones. There is also a possibility to restart them.		
Custom Bulk messages		
Added the ability to create custom messages by using values from uploaded CSV files.		

VolPInnovations Added VolP Innovations as an SMS provider.			
Other features			
	business	contact center	multi tenant
Enable jitterbuffer based on extension and tenant Configuration			
jitterbuffer on Extension. Jitterbuffer type: 1. Fixed - Set a fixed jitterbuffer on the channel. 2. Adaptive - Set an adaptive jitterbuffer on the channel. 3. Disabled - Remove a previously set jitterbuffer from the channel.			
Simplified Mobile app licensing			
Users are able to see mobile devices available on the system as one group of mobile devices. Both "iOS" and "Android" options are merged as single "Mobile Apps" option. This way customer buys "Mobile Apps" subscriptions and connects mobile apps regardless of the platform.			
Hide extension in desktop/mobile apps			
Option to enable/disable non-gloCOM extensions from displaying in gloCOM. Added on PBXware extension so system admin can manage (enable/disable) this option directly from PBXware GUI.			
Allow IP Address authentication for Extensions			
New field per tenant - Allow IP Address Authentication for Extensions and force IP based authentication. If option is disabled fields on extension: 1. Incoming IP Addresses 2. Insecure will be hidden.			
Renamed "Number of Digits" to "Extensions digit length".			
In the set-up wizard and in the option to create a new tenant "Number of digits" is changed to "Extension digit length" to avoid problems.	0	0	

Configurable features permissions		
Separate permissions are available for chat, voicemail, osc, agent pause, access codes, qos, directory and phone DND. Permissions are set per tenant and edition in PBXware.		
Control of MP3 conversion		
System settings option for audio conversion. Convert files to mp3, this will apply to system-wide recordings Select options from the drop-down: Convert and remove original Convert on listen / download Convert and keep original Do not convert Will leave files in the original format without conversion. (recordings can't be played from GUI).		
Keyboard friendly controls		
Using the tab key, users are able to access all links and controls in a predictable order based on their visual position on the page. User can tab over the "Yes/No/Not Set" buttons. Pressing enter while tabbed on a button will be the same as if you clicked on it with your mouse.		
CDR partitioning		
Partitioning enables tables to be subdivided into smaller manageable pieces and each small piece is called a "partition" which can be safely archived. Users can see reports in GUI Home > Reports > Archived reports and download archived files.		
Store Unanswered CDRs		
An option to exclude unanswered CDR records from a report. This option can be found under Extension > Ring Groups > Store Unanswered CDRs.		
Mobile applications and queue calls		
If there is a mobile application registered on an extension in the queue and when a call is received from the queue, the mobile application will not be awakened via the push service.		

Toggle directly to Advanced options screen On Tenants/Servers Edit there is a new option called "Show advanced options by Default". It is available on Master tenant and per Tenant, meaning that if the option is not set on Tenant the value set on Master Tenant will be used. If you set the option to "Yes" then the "Show Advanced Options" on pages will be			
automatically clicked and you need to confirm that everything is the same as if you clicked the option yourself.			
Custom statuses in PBXware			
So, on PBXware there would be a page where Admin could see a list of custom statuses, add new status, modify or delete old statuses. Each custom status has it's corresponding state type (Dropdown with 4 possible values) and status message (Text field which must not be empty). Also there should not be 2 custom statuses with the same message.			
Ability to disable chat for mobile applications			
Admin has ability to disable chat for users on mobile apps.			
Apps			
	business	contact center	multi tenant
Overview / CVS Download			
The Overview page displays a full list of Extensions on PBXware and assigned gloCOM Editions. This page is used to make the management of Edition administration easier in case users need to switch permissions among Extensions. Users can now click the 'CSV Download' button to download a CSV file with the information from the Overview page, which can be used for data collection and information management.			
Apps feature management			

Added the ability to enable/disable certain App features added per Tenant.

Site Accounts			
	business	contact center	multi tenant
Users force logout Added the option to force the logout of PBXware users and administrators.			
Search for groups $ Added \ search \ option \ for \ Admin \ \rightarrow \ Groups \ on \ MT \ edition. $			

Embedded documentation (Admin Setings)

	business	contact center	multi tenant
Enable			
Provides the ability to enable or disable Embedded Documentation			
Server type			
Provides the ability to select server, either default or custom. The default points to the Bicom Systems' default Tooltip server, and the custom option allows the user to set their own tooltip server to be used.			
Server URL			
Provides the ability to set up a custom Tooltip server URL if the custom server option is selected as the Server Type.			
Token			
Provides the ability to set an access token for custom Tooltip server URLs if the custom server option is selected as the Server Type.			
Product Name			
Branding option which allows custom product name to be shown in Embedded Documentation. PBXware is a default name if value is not set.			

Client App Name A branding option which allows custom Client App names to be shown in Embedded		
Documentation. If the custom value is not set, the default name listed will be gloCOM. Company Name		
A branding option which allows custom Company names to be shown in Embedded Documentation. If the custom value is not set, the default name shown will be Bicom Systems.		
The question mark icon in the top right corner of the toolbar Provides the ability to show/hide the tooltips in the PBXware interface.		

sipPROT integration (Setup Wizard)

	business	contact center	multi tenant
Install sipPROT			
With sipPROT enabled in your PBXware license, you will need to open your PBXware Setup Wizard up and navigate to the sipPROT section where you can install sipPROT with a single mouse click.			
sipPROT			
With sipPROT installed, all you need to do is click the "Open sipPROT" button to open the configuration page and access all of the amazing features that the new version of sipPROT has to offer.			
Update sipPROT			
Additionally, you can check for sipPROT updates by navigating to the Updates section of the Setup Wizard. If a new version is available, you will be able to update your installation.			

CONTACT BICOM SYSTEMS TODAY

to find out more about our services

Bicom Systems (USA)

2719 Hollywood Blvd

B-128

Hollywood, Florida

33020-4821

United States

Tel: +1 (954) 278 8470 Tel: +1 (619) 760 7777

Fax: +1 (954) 278 8471

Bicom Systems (CAN)

Hilyard Place

B-125

Saint John, New Brunswick

E2K 1J5

Canada

Tel: +1 (647) 313 1515

Tel: +1 (506) 635 1135

Bicom Systems (UK)

Unit 5 Rockware BC

5 Rockware Avenue

Greenford

UB6 OAA

United Kingdom

Tel: +44 (0) 20 33 99 88 00

Bicom Systems (FRA) c/o FONIA

Zac du Golf 15 Impasse Oihana

64200 BASSUSSARRY

Tel: +33 (0)5 64 115 115 Email: contact@fonia.fr

Bicom Systems (ITA)

Via Marie Curie 3 50051 Castelfiorentino

Firenze

Italy

Tel: +39 0571 1661119

Email: sales@bicomsystems.it

Bicom Systems (RSA)

12 Houtkapper Street

Magaliessig

2067

South Africa

Tel: +27 (10) 0011390

email: sales@bicomsystems.com

